### **FAX Option Type 2045**

# Operating Instructions Facsimile Reference <Advanced Features>



- 1 Transmission Mode
- 2 Checking and Canceling Transmission Files
- 3 Communication Information
- 4 Other Transmission Features
- 5 Reception Features
- 6 LAN-Fax Features
- 7 Simplifying the Operation
- 8 Facsimile Features
- 9 Key Operator Setting
- **10** Solving Operation Problems
- 11 Appendix



#### Introduction

This manual describes detailed instructions on the operation and notes about the use of this machine. To get maximum versatility from this machine all operators are requested to read this manual carefully and follow the instructions. Please keep this manual in a handy place near the machine.

#### **Notes**

Some illustrations in this manual might be slightly different from the machine.

Certain options might not be available in some countries. For details, please contact your local dealer.

Two kinds of size notation are employed in this manual. With this machine refer to the metric version.

#### **Important**

Contents of this manual are subject to change without prior notice. In no event will the company be liable for direct, indirect, special, incidental, or consequential damages as a result of handling or operating the machine.

#### **Trademarks**

Microsoft®, Windows® and Windows NT® are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Adobe® and Acrobat® are registered trademarks of Adobe Systems Incorporated.

Ethernet is a registered trademark of Xerox Corporation.

Other product names used herein are for identification purposes only and might be trademarks of their respective companies. We disclaim any and all rights in those marks.

#### Note

The proper names of the Windows operating systems are as follows:

- Microsoft<sup>®</sup> Windows<sup>®</sup> 95 operating system
- Microsoft<sup>®</sup> Windows<sup>®</sup> 98 operating system
- Microsoft<sup>®</sup> Windows<sup>®</sup> Millennium Edition (Windows Me)
- Microsoft® Windows® XP Professional
- Microsoft® Windows® XP Home Edition
- Microsoft<sup>®</sup> Windows<sup>®</sup> 2000 Server
- Microsoft® Windows® 2000 Professional
- Microsoft® Windows NT® Server operating system Version 4.0
- Microsoft® Windows NT® Workstation operating system Version 4.0

#### Manuals for This Machine

The following manuals describe the operational procedures of this machine. For particular functions, see the relevant parts of the manual.

#### Note

- ☐ Manuals provided are specific to machine type.
- ☐ Adobe Acrobat Reader is necessary to view the manuals as a PDF file.
- ☐ Two CD-ROMs are provided:
  - CD-ROM 1"Operating Instructions for Printer/Scanner"
  - CD-ROM 2"Scanner Driver & Document Management Utilities"

#### General Settings Guide

Provides an overview of the machine.

It also describes System Settings (such as paper trays and user codes settings), Document Server functions, and troubleshooting.

#### Network Guide (PDF file - CD-ROM1)

Describes procedures for configuring the machine and computers in a network environment.

#### Copy Reference

Describes operations, functions, and troubleshooting for the machine's copier function.

#### Facsimile Reference < Basic Features>

Describes operations, functions, and troubleshooting for the machine's facsimile function.

#### Facsimile Reference<Advanced Features>(this manual)

Describes advanced functions and settings for key operators.

#### Printer Reference 1

Describes system settings and operations for the machine's printer function.

#### ❖ Printer Reference 2 (PDF file - CD-ROM1)

Describes operations, functions, and troubleshooting for the machine's printer function.

#### **❖** Scanner Reference (PDF file - CD-ROM1)

Describes operations, functions, and troubleshooting for the machine's scanner function.

#### Manuals for DeskTopBinder V2 Lite

DeskTopBinder V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- DeskTopBinder V2 Lite Setup Guide (PDF file CD-ROM2)
   Describes installation of, and the operating environment for DeskTop-Binder V2 Lite in detail. This guide can be displayed from the [Setup] dialog box when DeskTopBinder V2 Lite is installed.
- DeskTopBinder V2 Lite Introduction Guide (PDF file CD-ROM2)
   Describes operations of DeskTopBinder V2 Lite and provides an overview of its functions. This guide is added to the [Start] menu when DeskTop-Binder V2 Lite is installed.
- Auto Document Link Guide (PDF file CD-ROM2)
   Describes operations and functions of Auto Document Link installed with DeskTopBinder V2 Lite. This guide is added to the [Start] menu when DeskTopBinder V2 Lite is installed.

#### Manuals for ScanRouter V2 Lite

ScanRouter V2 Lite is a utility included on the CD-ROM labeled "Scanner Driver & Document Management Utilities".

- ScanRouter V2 Lite Setup Guide (PDF file CD-ROM2)
   Describes installation of, settings, and the operating environment for Scan-Router V2 Lite in detail. This guide can be displayed from the [Setup] dialog box when ScanRouter V2 Lite is installed.
- ScanRouter V2 Lite Management Guide (PDF file CD-ROM2)
   Describes delivery server management and operations, and provides an overview of ScanRouter V2 Lite functions. This guide is added to the [Start] menu when ScanRouter V2 Lite is installed.

#### Other manuals

- PS3 Supplement (PDF file CD-ROM1)
- Unix Supplement (Available from an authorized dealer, or as a PDF file on our Web site.)

### **TABLE OF CONTENTS**

Manuals for This Machine	
How to Read This Manual	
Symbols	1
1. Transmission Mode	
Sending at a Specific Time (Send Later)	3
User Transmission	5
Priority Transmission	6
Confidential Transmission	7
Polling Transmission	9
Polling Transmission Clear Report	
Polling Reception	
Polling Reserve Report	
Polling Result Report	1ರ
2. Checking and Canceling Transmission Files	
Displaying Confirmation of Transmission	15
Canceling a Transmission	
Deleting a Destination	17
Adding a Destination	
Changing the Transmission Time	19
Printing a File	20
Resending a File	21
Printing a List of Files in Memory (Print TX File List)	22
3. Communication Information	
Printing the Journal	
Journal	
Checking the Transmission Result (TX File Status)	
Checking the Reception Result (RX File Status)	
Displaying the Memory Status	
Printing/Deleting Received and Stored Documents (Printing Stored RX File)	
Printing Received and Stored Documents  Deleting Received and Stored Documents	
Printing a Confidential Message	
Confidential File Report	
Printing a File Received with Memory Lock	
Personal Boxes	
Personal Boxes	
Printing Personal Box Messages	

Information Boxes	
Information Boxes	
Storing Messages in Information Boxes	38
Printing Information Box Messages	
Deleting Information Box Messages	41
4. Other Transmission Features	
Handy Dialing Functions	43
Chain Dial	
(Example) 01133-1-555333	43
Redial	43
Advanced Features	45
SUB Code	
SID Code	
SEP Code	46
PWD Code	47
Transfer Request	48
With Transfer Requests set in the System Settings	50
On Hook Dial	51
Manual Dial	52
Changing the Line Port	
Sub Transmission Mode	
Book Fax	
Two-Sided Transmission (Double-Sided Transmission)	
Standard Message Stamp	
Sending an Auto Document	
Printing documents stored as Auto Documents	
Sending a Stored File	
Sending stored documents	
Printing stored documents	
Stamp	
Transmission Options	
Fax Header Print	67
Label Insertion	68
Sender Stamp	68
Reduced Image Transmission	
Auto Reduce	
Default ID Transmission	
Selecting transmission options for a single transmission	69
More Transmission Functions	71
If Memory Runs Out While Storing an Original	71
Parallel Memory Transmission	71
Checking the Transmission Result	
Automatic Redial	
Batch Transmission	
ECM (Error Correction Mode)	
Broadcasting Sequence	
Checking the Transmission Progress	
Dual Access	73

Transmission with Image Rotation	73
Simultaneous Broadcast	73
JBIG Transmission	74
Printed Report	75
Memory Storage Report	
Transmission Result Report (Memory Transmission)	
Communication Failure Report	
Transmission Result Report (Immediate Transmission)	76
5. Reception Features	
Reception	77
Immediate Reception	77
Memory Reception	77
Substitute Reception	79
Receiving messages unconditionally	79
Receiving messages according to parameter-specified settings	80
Reception Functions	81
Transfer Station	81
Transfer result report	
JBIG Reception	82
Auto Fax Reception Power-up	83
Printing Options	84
Print Completion Beep	
Checkered Mark	84
Center Mark	84
Reception Time	85
Two-Sided Printing	85
180-Degree Rotation Printing	86
Multi-copy Reception	86
Image Rotation	87
Combine Two Originals	
Page Separation and Length Reduction	
Reverse Order Printing	
Page Reduction	
TSI Print (Transmitting Subscriber Identification Print)	
When There Is No Paper of the Correct Size	
Just Size Printing	
Setting Priority Trays	
Having Incoming Messages Printed on Paper from the Bypass Tray	
Where Incoming Message are Delivered - Output Tray	
Specifying Tray for Lines	
Tray Shift	93

#### 6. LAN-Fax Features

Sending Fax Documents from Computers	95
Installing the Software	
Auto Run Program	96 97
Installing Individual Applications	
Applications Stored on the CD-ROM	
LAN-Fax Driver	97
Address Book	98
LAN-Fax Cover Sheet Editor	98
Setting LAN-Fax Properties	98
Basic Transmission	
Attaching a cover sheet	
Previewing fax images	
Specifying options	
Printing or Saving as Files	
Address Book	
Editing Fax Cover Sheets	
Creating a cover sheet	
Attaching a created cover sheet	
LAN-Fax Operation Messages	
LAN-Fax Error Report	
Error messages	
Viewing Fax Information Using a Web Browser	109
Viewing and/or Printing Received Fax Messages Using a Web Browser	109
Viewing received fax messages using a Web browser	
Printing fax information using a Web browser	110
Deleting fax information using a Web browser	110
Viewing Received Messages on a Computer	111
Delivering Received Messages	111
7. Simplifying the Operation	
Programs	
Registering and Changing Keystroke Programs	
Registering a priority function using a program	
Using a program	
Changing a program name	
Deleting a Program	
Using the Document Server	
Storing a Document	
File Manage	
Delete File	
Managing Documents Saved in the Document Server from a Computer	
Using DesktopBinder	
Using a Web browser	123

### 8. Facsimile Features

Function List	125
Accessing User Tools (Facsimile Features)	129
Quitting Default Settings	
General Settings/Adjustment	
Reception Setting	132
9. Key Operator Setting	
Key Operator Tools List	135
Using Key Operator Settings	
Programming, Changing, and Deleting Standard Messages	
Deleting Standard Messages	
Storing, Changing, and Deleting an Auto Document	
Deleting an Auto Document Programming and Changing a Scan Size	
Deleting a Scan Size	
Printing the Journal	
Counters	
Forwarding	
Programming an end receiver	
Quitting the forwarding function	
Forwarding mark	
Memory Lock	
ECM	
Changing the User ParametersChanging the User Parameters	
Printing the User Parameter list	
Special Senders to Treat Differently	
Programming/Changing Special Senders	
Programming Initial Set Up of a Special Sender	
Deleting a Special Sender	159
Printing the Special Sender list	
Box Settings	
Programming/editing Personal Boxes	
Deleting Personal Boxes	
Programming/editing Information Boxes  Deleting Information Boxes	
Programming/editing Transfer Boxes	
Deleting Transfer Boxes	
Printing the box list	
Transfer Report	
Programming a Confidential ID	
Programming a Polling ID	
Programming a Memory Lock ID	
Selecting Dial/Push Phone	
Storing or Printing Received Documents	
Setting a User Code for Viewing Received and Stored Documen	າເຣ1/3

### 10. Solving Operation Problems

Reading Reports	<b>175</b> 175
11.Appendix	
Replacing the Stamp Cartridge	177
Connecting the Machine to a Telephone Line and Telephone	178
Connecting the Telephone Line	
Selecting the Line Type	178
Optional Equipment	179
Fax Function Upgrade Unit	
Expansion Memory (32MB: DIMM)	
Extra G3 Interface Unit	
Specifications	180
Acceptable Types of Originals	
Acceptable original sizes	
Paper size and scanned area	181
Maximum Values	
INDEX	186

### How to Read This Manual

#### **Symbols**

In this manual, the following symbols are used:

#### **⚠ WARNING:**

This symbol indicates a potentially hazardous situation that might result in death or serious injury when you misuse the machine without following the instructions under this symbol. Be sure to read the instructions, all of which are included in "Safety Information", *General Settings Guide*.

#### **A CAUTION:**

This symbol indicates a potentially hazardous situation that might result in minor or moderate injury or property damage that does not involve personal injury when you misuse the machine without following the instructions under this symbol. Be sure to read the instructions, all of which are included in "Safety Information", *General Settings Guide*.

\* The statements above are notes for your safety.

#### **#Important**

If this instruction is not followed, paper might be misfed, originals might be damaged, or data might be lost. Be sure to read this.

#### Preparation

This symbol indicates information or preparations required prior to operating.

#### **𝚱** Note

This symbol indicates precautions for operation, or actions to take after abnormal operation.

#### Limitation

This symbol indicates numerical limits, functions that cannot be used together, or conditions under which a particular function cannot be used.

#### 

This symbol indicates a reference.

[ ]

Keys that appear on the machine's panel display.

[ ]


Keys and buttons that appear on the computer's display.

Keys built into the machine's control panel.

### 1. Transmission Mode

### Sending at a Specific Time (Send Later)

Using this function, you can instruct the machine to delay transmission of your fax message until a specified later time. This allows you to take advantage of off-peak telephone charges without having to be by the machine at the time.



If you have a non-urgent fax, select Send Later with Economy Transmission when you scan it. Faxes will be queued in memory and sent during Economy Transmission Time.

#### **∰**Important

☐ After the machine has been switched off for about one hour, all fax messages stored in memory are lost. If messages are lost for this reason, a Power Failure Report is automatically printed when the operation switch is turned on. Use this report to identify lost messages.

#### Limitation

☐ This function is unavailable with Immediate Transmission. Use Memory Transmission.


#### Note

- ☐ You can specify a time within 24 hours.
- ☐ If the current time shown is not correct, change it. See the *General Settings Guide*.
- ☐ For convenience, you can program the time when your phone charges become cheaper as the Economy Transmission Time. See p.131 "Program Economy Time".
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps ② and ⑤.
- 1 Place the original, and then select the scan settings you require.

#### 


p.11 "Placing Originals", Facsimile Reference <Basic Features> p.27 "Scan Settings", Facsimile Reference <Basic Features>

### **2** Press [Transmission Mode].



**3** Select [Send Later].

Enter the time using the number keys (24 hr format), and then press [OK].



The specified time is shown above the highlighted [Send Later].

#### **𝚱** Note

- ☐ Press **[Economy Time]** to specify the economy time.
- ☐ When entering numbers smaller than 10, add a zero at the beginning.
- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ To cancel Send Later, press **[Cancel]**. The display returns to that of step **[3**].

### Press [OK].

- Note
- ☐ To check the settings, press [Transmission Mode].
- Dial and press the [Start] key.
  - Note
  - ☐ You can cancel the transmission setup for Send Later. See p.16 "Canceling a Transmission".

#### 1

### **User Transmission**

This function allows you to check each user or department's transmission history. To use the function, you need to program a user code (eight digits max.) for each user or department, to be entered before transmission. See the *General Settings Guide*.


#### Note

- ☐ You can program codes of up to 8 digits for a maximum of 100 users and/or departments. With the optional account enhance module installed, you can program user codes for a maximum of 500 users and/or departments. See the *General Settings Guide*.
- ☐ You can enter user codes or names into various lists or reports.
- 1 Place the original, and then select desired scan settings.

#### 


p.27 "Scan Settings", Facsimile Reference <Basic Features>

**2** Press [Transmission Mode].



Press [User TX].

4 Using the number keys enter a user code (up to eight characters), and then press [#].



The programmed user name will appear.

#### Note

- ☐ If you enter a wrong code, press [Clear] or the [Clear/Stop] key before pressing [∰], and then try again.
- ☐ To cancel the operation, press [Cancel]. The display returns to that of step [3].

### **5** Press [OK].

The standby display appears.

#### **𝚱** Note


- ☐ To check the settings, press [Transmission Mode].
- 6 Specify a destination, and then press the [Start] key.

#### Note

☐ You can cancel the transmission setup for User Transmission. See p.16 "Canceling a Transmission".

### **Priority Transmission**

Documents you send with Memory Transmission are sent in the order they are scanned. Therefore, if several messages are queued in memory, the next document will not be sent immediately. However, by using this function you can have your message sent before other queued messages.



#### Limitation

☐ This function is not available with Immediate Transmission. If this function is selected, the machine automatically switches to Memory Transmission.


#### Note

- ☐ If there is already a message stored with this function or a transmission in progress, your message will be sent after that message has been transmitted.
- 1 Place the original, and then select the scan settings you require.


#### 

p.27 "Scan Settings", Facsimile Reference <Basic Features>

### **2** Press [Transmission Mode].



Select [Priority TX], and then press [OK].




- **𝚱** Note
- ☐ To check the settings, press [Transmission Mode].
- Dial, and then press the [Start] key.
  - Ø Note
  - ☐ Press [Change/Stop TX File] to cancel the transmission.

#### 1

### **Confidential Transmission**

If you want to limit who views your message, use this function. The message will be stored in memory at the other end and not printed until an ID is entered.



There are two types of Confidential Transmission:

#### Default ID

It is not necessary to enter an ID when transmitting.

The other party can print the message by entering the Confidential ID programmed in their machine.

#### ID Override

Should you want to send a confidential message to a particular person at the other end, you can specify the Confidential ID that the receiver has to enter to see that message. Before you send the message, do not forget to tell the receiver the ID that must be entered to print the message.

#### Limitation

- ☐ The destination machine must be of the same manufacturer and have the Confidential Reception function.
- ☐ The destination machine must have enough memory available.

#### Note


- ☐ We recommend that you program the Confidential ID beforehand. See p.170 "Programming a Confidential ID".
- ☐ An ID can be any 4-digit number (except 0000).
- ☐ If the destination machine is not of the same manufacturer, you can use Confidential Transmission with "SUB Code". See p.45 "SUB Code".
- 1 Place the original, and then select the scan settings you require.

#### 

p.11 "Placing Originals", Facsimile Reference <Basic Features>


p.27 "Scan Settings", Facsimile Reference <Basic Features>

### **2** Press [Transmission Mode].



3 Select [Confidential TX].

Depending on the Confidential Transmission type, use one of the following procedures:



#### Default ID

• Check that [Default ID] has been selected, and then press [OK].


"Default ID" is shown above the highlighted [Confidential TX].



☐ To cancel Contidential Transmission, press [Cancel]. The display returns to that of step §.

#### Override ID

- Press [ID Override].
- 2 Enter the Confidential ID (4-digit number) using the number keys, and then press [OK].



"ID Override" and the entered Confidential ID are shown above the highlighted [Confidential TX].

#### 

- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ To cancel Confidential Transmission, press [Cancel]. The display returns to that of step 3.


### Press [OK].

- Note
- ☐ To check the settings, press [Transmission Mode].
- Dial, and then press the [Start] key.
  - **𝒯** Note
  - ☐ You can cancel the transmission setup for Confidential Transmission. See p.16 "Canceling a Transmission".

#### 1

### **Polling Transmission**

Use Polling Transmission when you want to leave an original in the machine memory for others to pick up. The message will be sent when the other party calls you up.



There are three types of Polling Transmission.

#### Free Polling Transmission

It is not necessary to enter the Polling ID during the procedure. Anybody can poll the message from your machine. The machine sends it regardless of whether Polling ID's match.

#### **♦** Default ID Transmission

It is not necessary to enter the Polling ID during the procedure. The message will only be sent if the Polling ID of the machine trying to poll your message is the same as the Polling ID stored in your machine. Make sure in advance that both machines' Polling IDs are identical.

#### ID Override Transmission

You must enter an Override Polling ID unique to the transmission. This ID overrides the ID stored in the machine. The user must supply this ID when they poll your machine. If the IDs match, the message is sent. Make sure in advance the other end knows the ID you are using.

#### Limitation

- ☐ Polling Transmission is allowed only if the receiver's machine has the Polling Reception function.
- ☐ Usually, only machines of the same manufacturer that support Polling Reception can perform ID Polling Transmission. However, when the Information Box File function is used, and the other party's fax machine supports Polling Transmission and the SEP function, you can still carry out Polling Transmission with an ID. See p.38 "Information Boxes".

#### Note


- ☐ Free Polling and Default ID Transmission allow only one file to be stored in memory.
- ☐ ID Override Polling Transmission allows a file to be stored in memory for each ID; you can store up to 400 files (800 with the optional fax function upgrade unit) by changing IDs.
- ☐ Before using Default ID Transmission, you need to program the Polling ID. See p.170 "Programming a Polling ID".

- ☐ You can set whether a Polling Transmission file is deleted after transmitting in "User Parameters". To save the file to transmit repeatedly, set to "Standby (Save)". See p.147 "Changing the User Parameters" (switch 11, bit 7).
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps ② and ⑤.
- ☐ The communication fee is charged to the receiver.
- 1 Place the original, and then select the scan settings you require.


#### 

p.11 "Placing Originals", Facsimile Reference <Basic Features> p.27 "Scan Settings", Facsimile Reference <Basic Features>

**2** Press [Transmission Mode].



- 3 Select [Polling TX].
- Depending on the Polling Transmission mode, use one of the following procedures:




#### Free Polling Transmission

• Check that [Free Polling TX] is selected.

#### **Default ID Transmission**

- 1 Select [Default ID TX].
- **ID Override Transmission**
- **1** Select [ID Override Transmission].
- Specify a 4-digit ID using the number keys and [A], [B], [C], [D], [E], and [F].



- Note
- ☐ A Polling ID may be any four numbers (0 to 9) and characters (A to F), except 0000 and FFFF.
- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key, and then try again.
- Press [Only Once] or [Save] to delete or save the file after transmission.
  - **𝒯** Note
  - ☐ To delete the original immediately after transmission, select [Only Once].
  - ☐ To repeatedly send the original, select **[Save]**.
  - ☐ To cancel Polling Transmission, press [Cancel]. The display returns to that of step 3.

6 Press [OK].

"**XXXXXXXX**" appears.

The type of Polling Transmission is shown above the highlighted [Polling TX].

- **7** Press [OK].
  - Ø Note
  - ☐ To check the settings, press [Transmission Mode].
- 8 Press the [Start] key.
  - **𝚱** Note
  - ☐ You can cancel the transmission setup for Polling Transmission. See p.16 "Canceling a Transmission".

## Polling Transmission Clear Report

This report allows you to verify whether Polling Transmission has taken place.

#### Limitation


☐ This report is not printed if the User Parameters are set to allow the stored originals to be repeatedly sent (Save). See p.147 "Changing the User Parameters" (switch 11, bit 7).

#### Note

- ☐ You can turn this function on or off with the User Parameters. See p.147 "Changing the User Parameters" (switch 03, bit 6).
- ☐ You can have a portion of the sent image printed on the report with the User Parameters. See p.147 "Changing the User Parameters" (switch 04, bit 7).
- ☐ You can check the result of Polling Transmission with the Journal. See p.23 "Printing the Journal"

H

Use this function to poll a message from another terminal. You can also poll documents from many terminals with only one operation (use Groups and Keystroke Programs to fully exploit this function).



There are two types of Polling Reception.

#### Default ID/Free Polling Reception

Use this method for Free Polling or Default ID Polling. If the Polling ID is programmed in your machine, any messages waiting in the transmitting machine with the same ID are received. If the other machine does not have any messages waiting with the same Polling ID, any messages that do not require ID are received (Free Polling).

#### ID Override Polling Reception

You must enter an Override Polling ID unique to this transmission. This ID overrides the one stored in this machine.


Your machine will receive any messages waiting in the transmitting machine that have matching ID's. If no ID's match, any messages that do not require IDs are received (Free Polling).

#### Limitation


- ☐ Polling Reception requires that the other machine is capable of Polling Transmission.
- ☐ Usually, you can only receive documents with a Polling ID from machines of the same manufacturer that support the polling function. However, if the other party's fax machine supports Polling Transmissions and the SEP function, and also has stored IDs, you can still perform Polling Reception. See p.46 "SEP Code".
- ☐ To receive a message sent by Default ID Polling Transmission or ID Override Polling Transmission, it is necessary to specify the same Polling ID as the sender's.
- ☐ To receive a message sent by Free Polling Transmission, it is not necessary to specify the same Polling ID as the sender's.

#### **𝚱** Note

- ☐ For ID Polling Reception, program a Polling ID in advance. See p.170 "Programming a Polling ID".
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps **1** and **2**.
- **1** Press [Transmission Mode].



- 2 Select [Polling RX].
- Depending on which method you are using, select one of the following procedures:




#### Default ID/Free Polling Reception

• Check that [Default ID/Free Polling RX] is selected, and then press [OK].

"Deflt ID/Free Poll." is shown above the highlighted [Polling RX].

- Note
- ☐ To cancel Polling Reception, press [Cancel]. The display returns to that of step ②.
- **ID Override Polling Reception**
- Press [ID Override Polling Reception].
- 2 Specify a 4-digit ID using the number keys and [A], [B], [C], [D], [E], and [F], and then press [OK].



"ID Override" and the entered Polling ID are shown above the highlighted [Polling RX].

#### Note

- ☐ A Polling ID may be any four numbers (0 to 9) and characters (A to F), except 0000 and FFFF.
- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ To cancel Polling Reception, press [Cancel]. The display returns to that of step ②.
- 4 Press [OK].

The standby display appears.

Dial, and then press the [Start] key.

#### Polling Reserve Report

This report is printed after Polling Reception has been set up.

- ☐ You can turn this function on or off with the User Parameters. See p.147 "Changing the User Parameters" (switch 03, bit 3).

#### **Polling Result Report**

This report is printed after a Polling Reception has been completed and shows its result.

- Note
- ☐ You can also check the result of a Polling Reception with the Journal. See p.23 "Printing the Journal".
- ☐ You can turn this function on or off with the User Parameters. See p.147 "Changing the User Parameters" (switch 03, bit 4).

### 2. Checking and Canceling Transmission Files

After you have pressed the **[Start]** key (after scanning originals), you can check and edit the destination or settings of Memory Transmission. You can also cancel a transmission, change the settings of a transmission, print a stored file, print a list of stored files, and resend a file which the machine failed to transmit.


This function is available for Memory Transmission, Confidential Transmission, Transfer Request, Polling Reception, and Polling Transmission.

#### Ø Note

- ☐ If there are no files being sent, received, or stored by Memory Transmission, **[Change/Stop TX File]** does not appear on the display.
- ☐ You cannot check or edit a file being sent or received. Also a Confidential Transmission file or stored file to be printed as a report cannot be checked or edited.

### **Displaying Confirmation of Transmission**

1 Press [Change/Stop TX File].



2 Select [Check/Change Settings].



Select files to be changed or checked.



- Ø Note
- ☐ If multiple destinations were specified, only the destination selected first appears.
- ☐ If multiple destinations were specified, only the number of unsent messages appears.
- 4 Check a file, and then press [Exit].
- **5** Press [Exit].


### **Canceling a Transmission**

You can cancel transmission of a file when the file is being sent, stored in memory, or fails to transmit. All the scanned data is deleted from memory.

You can cancel a file for Memory Transmission. This function is useful to cancel a transmission when you notice a mistake in destination or with the originals after storing. To cancel Memory Transmission, search for the file to be canceled among the files stored in memory, and then delete it.

#### Note

- ☐ If you cancel a transmission while the file is being sent, some pages of your file may have already been sent and will be received at the other end.
- ☐ If the transmission finishes while you are carrying out this procedure, transmission cannot be canceled.
- 1 Press [Change/Stop TX File].



**2** Select the files whose transmission you want to cancel.



#### Note

- ☐ To display only the files being sent, press [Files under TX].
- ☐ If multiple destinations were specified, only the number of unsent messages appears.
- ☐ If multiple destinations were specified, only one destination number appears. To display all destinations, press [Check/Change Settings].

### **3** Press [Stop Transmission].

The selected file is deleted.

#### Note

- ☐ To quit transmission cancel, press [Save].
- ☐ To cancel another transmission, repeat from step ②.


### 4 Press [Exit].

### **Deleting a Destination**

You can delete destinations.

#### **𝚱** Note


- ☐ If you delete a destination that is the only destination for a transmission, the transmission is canceled.
- 1 Press [Change/Stop TX File].




2 Press [Check/Change Settings].




Select the file from which you want to delete a destination.



4 Press [Change] for the destination you want to delete.




Press [Clear] to delete the destination.



- 6 Press [Exit].
  - Note
  - ☐ To delete another destination, repeat from step 3.
- **7** Press [Exit].

### **Adding a Destination**

1 Press [Change/Stop TX File].




2 Press [Check/Change Settings].




**3** Select the file to which you want to add a destination.



4 Press [Add].



**5** Specify the destination.



Note


- ☐ You can specify the destination using the number keys or soft (on-screen) keys.
- ☐ You can also program a SUB code and Sub-address by pressing [Adv. Features].
- 6 Press [Exit].
  - **𝚱** Note
  - ☐ Repeat steps **4** and **5**, if you want to add another destination.
- **7** Press [Exit].

### Changing the Transmission Time

You can change the transmission time specified with Send Later. See p.3 "Sending at a Specific Time (Send Later)".

You can also delete the transmission time. If the transmission time is deleted, the file is transmitted immediately.


1 Press [Change/Stop TX File].




2 Press [Check/Change Settings].




Select the file for which you want to change or cancel the transmission time.



4 Press [Change TX time].



Press [Clear], and then reenter the transmission time using the number keys or select [Economy Time], and then press [OK].




- Ø Note
- ☐ If you select **[Economy Time]**, the economy time already specified is entered. See p.130 "General Settings/Adjustment".
- ☐ If you press [Transmit Now], the file is transmitted immediately. However, if there is a file on standby, that file is sent first.
- 6 Press [Exit].
  - Note
  - ☐ Repeat from step **②**, if you want to change another transmission time.
- **7** Press [Exit].

### Printing a File

If you want to check the contents of a file that is stored in memory and not yet sent, use this procedure to print it out.

#### Note


- ☐ Confidential Transmission files are displayed, but cannot be printed.
- ☐ You can also print files that have not been successfully transmitted.
- 1 Press [Change/Stop TX File].



Press [Print File].



**3** Select the file you want to print.



#### Note

- ☐ If multiple destinations were specified, only the number of unsent messages appears.
- ☐ If you want two-sided printing (optional), press [Print 2 Sides].
- ☐ To cancel printing, press [Cancel]. The display returns to that of step 3.
- 4 Press the [Start] key.

#### Note

☐ To cancel printing after pressing the **[Start]** key, press **[Stop Printing]**. The display returns to that of step **§**.

### **5** Press [Exit].

The standby display appears.

#### Note

☐ Repeat from step **3**, if you want to print another file.

### Resending a File


Machine memory stores messages that could not be successfully transmitted using Memory Transmission. Use this procedure to resend these messages.

#### Preparation


You should select "Store for 24 hours" for "Store a message that could not be transmitted" in User Parameters. See p.147 "Changing the User Parameters" (switch 24, bit 0).

#### Ø Note

- ☐ Files that could not be transmitted will be kept for either 24 or 72 hours depending on how you program this function. See p.147 "Changing the User Parameters" (switch 24, bit 1).
- 1 Press [Change/Stop TX File].




2 Press [Transmit Failed File].



### **3** Select the file you want to resend.

"TX failed" is displayed for files that could not be sent.



#### 

- ☐ If multiple destinations were specified, only the destination number appears.
- ☐ If multiple destinations were specified, only the number of unsent messages appears.

### 4 Press [OK].

#### Note

- ☐ To add destinations, press [Add], and then specify the destinations.
- ☐ To cancel transmissions, press [Cancel]. The display returns to that of step ②.
- ☐ Repeat from step **3** to resend another file.

### Press [Exit].

The standby display appears.


Transmission starts.

# Printing a List of Files in Memory (Print TX File List)


Print this list if you want to find out which files are stored in memory and what their file numbers are. Knowing the file number can be useful (for example when erasing files).

#### **𝚱** Note

- ☐ The contents of a file stored in memory can also be printed. See p.20 "Printing a File".
- 1 Press [Change/Stop TX File].



2 Press [Print List].



#### Note

☐ To cancel printing after pressing the **[Start]** key, press **[Cancel]**. The display returns to that of step **2**.

### 3 Press the [Start] key.

#### Note

- ☐ To cancel printing after pressing the **[Start]** key, press **[Stop Printing]**. The display returns to that of step **2**.
- 4 Press [Exit].

### 3. Communication Information

### **Printing the Journal**

The Journal contains information about the last 50 communications (maximum) made by your machine. It is printed automatically after every 50 communications (receptions & transmissions).

You can also print a copy of the Journal at any time by following the procedure below.

If the machine is installed with the optional extra G3 interface unit, you can print the Journal of each line type.

#### ∰Important

☐ The contents of a Journal printed automatically are deleted after printing. Keep the journal if you require a record of transmissions and receptions. You can check a total of 200 communications (receptions & transmissions) on the display.

#### ◆ All

Prints the results of communications in the order made.

#### Print per File No.


Prints only the results of communications specified by file number.

#### Print per User Code

Prints only the results of communications through User Code Management or User Transmission. See p.8 "User Code Entry Display", Facsimile Reference < Basic Features> and p.5 "User Transmission".


#### 

- ☐ The setting on the machine can be changed so that user codes will be printed instead of user names. For more information, contact your service representative.
- ☐ The sender name column of the Journal is useful when you need to program a special sender. See p.152 "Special Senders to Treat Differently".
- ☐ You can set whether the Journal is automatically printed after every 50 communications in User Parameters. See p.147 "Changing the User Parameters" (switch 03, bit 7).
- ☐ You can set whether you print the Journal by line type. See p.147 "Changing the User Parameters" (switch 19, bit 1).
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps **1** and **2**.
- 1 Press [Information].



2 Select [Print Journal].

### 3 Select a printing mode.




#### Selecting [All]

• Press [All].

#### Selecting [Print per File No.]

- Press [Print per File No.].
- 2 Enter a 4-digit file number.




#### Note

☐ If you make a mistake, press [Clear] or the [Clear/Stop] key, and then try again.

#### Selecting [Print per User Code]


- Press [Print per User Code].
- 2 Specify an 8-digit user code using the number keys, and then press [#].



#### Ø Note

- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [∰], and then try again.
- **3** Check the user name shown on the display.
- 4 Press the [Start] key.
  - Note
  - ☐ To cancel a file printing, press [Stop Printing]. The display returns to that of step ②.
- Press [Exit] twice.

#### **Journal**



#### 1. Printing date

Shows the date and time when the report is printed.

#### 2. Programmed sender name

Shows the sender name programmed for printing.

#### 3. Date

Shows the transmission or reception date.

#### 4. Time

Shows the transmission or reception start time.

#### 5. Other end

Shows the sender name (for display) programmed by the other end. Shows the programmed sender fax number if the sender name (for display) has not been programmed.

If neither sender name nor fax number has been programmed by the other end, an entered fax number or a name programmed in a Destination list is shown for transmissions. The space will be blank for receptions.

#### 6. Communication mode

Shows a communication mode after transmission or reception. If the optional Extra G3 interface unit has been installed, "G3-1", "G3-2", or "G3-3" will be shown.

#### 7. Communication time

Shows time taken for transmissions or receptions.

#### 8. Number of pages

Shows the number of pages transmitted or received.

#### 9. Communication result

Shows the result of transmissions or receptions.

OK: All pages were properly transmitted or received.

Error: A communication error occurred.

???: Power was disconnected during communication. Not all fax messages were transmitted.

#### 10. User name

Shows the user name registered for user code use restriction or User Transmission.

#### 11. File number


Shows file management numbers.

# Checking the Transmission Result (TX File Status)


You can browse a part of the Transmission Result Report on the display.

#### Ø Note

- ☐ Only the transmission result of the last 200 communications (receptions & transmissions) are shown.
- ☐ If a transmission is completed while you are using this function, the result will not appear. To view the latest result, exit TX File Status, and then try again.
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps **1** and **2**.
- 1 Press [Information].



- 2 Select [TX File Status].
- 3 Check the transmission results.



Transmission results are displayed, from the latest result down, in groups of six.

#### Note

☐ "Destination" shows the Own Fax Number or Fax Header information of a receiver. For a transmission from a computer, "-- LAN-Fax -->" is shown.

## 4 Press [Exit] twice.

# Checking the Reception Result (RX File Status)


You can browse a part of the Reception Result Report on the display.

#### Ø Note

- ☐ Only the reception result of the last 200 communications (receptions & transmissions) are shown.
- ☐ If a message is received while you are using this function, the result will not appear. To view the latest result, exit RX File Status, and then try again.
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps **1** and **2**.
- 1 Press [Information].



- 2 Select [RX File Status].
- Check the reception results.



Reception results are displayed from the latest result in groups of six.

#### 


☐ Transmission Station shows the fax number of a sender or Fax Header information.

## 4 Press [Exit] twice.


## **Displaying the Memory Status**

Use this function to display a summary of current memory usage. Items shown are the percentage of free memory space, the number of received confidential messages, the number of files to be sent, the number of Memory Lock files and the number of received messages to be printed.

1 Press [Information].



- **2** Press [Memory Status].
- **3** Check the memory status.




- Note
- ☐ "Others" will be displayed:
  - When storing attachment files. See p.138 "Storing, Changing, and Deleting an Auto Document".
  - When storing Transfer Request files. See p.48 "Transfer Request".
  - When storing originals in the Information Boxes. See p.38 "Information Boxes".

- When sending to the Personal al Box. See p.36 "Personal Boxes".
- ☐ If you have made the machine save received messages on the hard disk, see "RX Print Standby File" on the display to check the number.
- 4 Press [Exit] twice.

# Printing/Deleting Received and Stored Documents (Printing Stored RX File)

The optional printer/scanner unit or network board is required. When the network board is used, the optional SDRAM 128 MB is also required.

You can print documents that are received and stored on the hard disk. You can also delete unwanted documents.



### **Preparation**

Make a setting for received and stored documents before using this function. See p.172 "Storing or Printing Received Documents".

#### **𝚱** Note


☐ You can view and/or print received and stored documents using a Web browser. See p.109 "Viewing Fax Information Using a Web Browser".

## Printing Received and Stored Documents


Use the following procedure to print documents saved on the hard disk.

#### Note

- ☐ This function allows you to print only received and stored documents.
- ☐ Received documents cannot be used for the Document Server function.
- ☐ You can specify and print multiple documents. You can specify a maximum of 30 documents at one time.
- 1 Press [Information].



- 2 Press [Print Stored RX File].
- Select the document to be printed, and then press [Print].



Select the printing mode, and then press the [Start] key.

#### Note

- ☐ To cancel printing, press [Cancel]. The display returns to that of step [3].
- ☐ To delete the document after printing, press [Delete File after Printing].
- ☐ To perform 2-sided printing (optional duplex unit required), press [Print on 2 sides] before pressing the [Start] key.
- Press [Exit] twice.


The standby display appears.

## Deleting Received and Stored Documents


Use the following procedure to delete documents stored on the hard disk.

#### Note

- ☐ You cannot delete a document while another person is viewing or printing it using a Web browser.
- 1 Press [Information].



- Press [Print Stored RX File].
- 3 Select the document to be deleted, and then press [Delete].



Press [Yes].

#### Ø Note

- ☐ To cancel a deletion, press [No]. The display returns to that of step 3.
- **5** Press [Exit] twice.

## **Printing a Confidential Message**

This function is designed to prevent unauthorized users from reading your messages. If someone sends you a message using Confidential Transmission, it is stored in memory but not automatically printed. To print the message you have to enter the Confidential ID Code. When your machine has received a confidential message, the **Confidential File** (Y) indicator lights.

## Preparation

Before using this function, program your Confidential ID. See p.170 "Programming a Confidential ID".

#### **∰**Important


☐ If the main power switch is off more than one hour, all confidential messages are deleted. When this happens, use the Power Failure Report to identify which messages have been deleted. See p.175 "Power Failure Report".

#### Limitation


You must program the Confidential ID for Confidential Reception to work.

#### Note

☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps ② and ⑤. 1 Confirm that the Confidential File indicator is lit.




**2** Press [Information].



3 Select [Print Confidential RX File].

#### Note

- ☐ If no confidential messages have been received, the message "No reception file." is shown. Press [Exit].
- Enter a 4-digit Confidential ID using the number keys, and then press the [Start] key.



#### Note

- ☐ You must enter the Confidential ID programmed in this machine, if the received file has no Confidential ID.
- ☐ You must enter the Confidential ID programmed by the sender. Confirm the sender's Confidential ID in advance.
- ☐ If the Confidential IDs or Personal Confidential IDs do not match, the message "No reception file under specified Confidential ID." appears. Press [Exit] to cancel the operation, and then check the Confidential ID or Personal Confidential ID with the other party, and then try again.

## **5** Press [Exit].

The standby display appears.

# If you cannot print confidential files even if the Confidential File (団) indicator is lit.

The Confidential File indicator also lights if the machine received a message with a SUB code. Check the Personal Boxes.

#### Note

☐ Print from the Personal Box, when a file has been sent from another party with a SUB code attached. See p.36 "Personal Boxes".

#### **Confidential File Report**

When this function is turned on, this report is printed whenever your machine receives a confidential message.

#### Note

☐ You can turn this function on or off with the User Parameters. See p.147 "Changing the User Parameters" (switch 04, bit 0).

## Printing a File Received with Memory Lock

This is a security function designed to prevent unauthorized users from reading your messages. If Memory Lock is switched on, all received messages are stored in memory and are not automatically printed. To print the messages, you have to enter the Memory Lock ID Code. When your machine has received a message with Memory Lock, the **Confidential File** (Y) indicator blinks.

## Preparation

Before using this function, program your Memory Lock ID. See p.171 "Programming a Memory Lock ID".

Before using this function, set Confidential Transmissions to On.


#### **∰**Important

☐ If the main power switch is turned off for more than an hour, all messages protected by Memory Lock will be deleted. In that case, the Power Failure Report will be printed so you can confirm which messages have been deleted. See p.175 "Power Failure Report".


#### Note

- ☐ If free memory space is low, messages may not be received.
- ☐ You can also apply a Memory Lock to messages that come only from certain senders. See p.152 "Special Senders to Treat Differently".
- ☐ Messages received by Polling Reception are automatically printed even if this function is switched on.
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps ② and ⑤.

1 Confirm that the Confidential File indicator is blinking.




2 Press [Information].



- **3** Select [Print Memory Lock].

  - ☐ If no messages were received while Memory Lock was switched on, the message "No reception file." is shown. Press [Exit].
- 4 Enter a 4-digit Memory Lock ID with the number keys, and then press the [Start] key.



#### Note

☐ If the Memory Lock ID does not match, the message "Specified code does not correspond to programed Memory Lock ID." appears. Press [Exit] and retry after checking the Memory Lock ID.

## Press [Exit].


## **Personal Boxes**

#### Preparation

Before using this function, set the Personal Box in advance. See p.161 "Programming/editing Personal Boxes".

#### **Personal Boxes**

This function lets you set up the machine so that incoming messages addressed to certain users are stored in memory instead of being printed out immediately. Each user must be assigned a SUB code (Personal Code) that has been designated as a Personal Box beforehand. When the other party sends their message, they specify the SUB code of the user to which they are sending. When the message is received, it is stored in the Personal Box with the matching SUB code. In order to print a message received into a Personal Box, you must enter the SUB code assigned to that Personal Box. This enables several individuals or departments to share a single fax machine yet be able to differentiate between messages. Furthermore, if you specify a receiver for the Personal Box, instead of being stored in memory, incoming messages with this SUB code appended are forwarded directly to the destination you specify.



- To be able to receive messages into a Personal Box you must inform the sender of the SUB code registered for that Personal Box and ask them to send the message using SUB Code Transmission with that SUB code. See p.45 "SUB Code".
- When messages have been received into Personal Boxes, the Confidential Reception/Memory Lock indicator lights and the Confidential File Report is printed. See p.33 "Confidential File Report".
- If a Personal Box is assigned a receiver, incoming messages are transferred to that receiver with a Forwarding Mark stamped on them. See p.143 "Forwarding".
- If a receiver is not assigned, print these messages. See p.36 "Printing Personal Box Messages".


## **Printing Personal Box** Messages

Follow these steps to print a message that has been received into a Personal Box.

#### Note


☐ If you print a Personal Box message, it is deleted.

#### 1 Confirm that the Confidential File indicator is lit.




7HPS061E

## 2 Press [Information].



- **3** Select [Print Personal Box File].
- Select the box with the message you want to print.




#### When a password is required

The display appears, when the selected Personal Box password is set in advance.

#### Note

- ☐ The password is registered in "Key Operator Tools". See p.161 "Programming/editing Personal Boxes".
- Enter the password, and then press [OK].



#### Ø Note

- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ To cancel entering a password, press [Cancel]. The display returns to that of step 4.

## Press the [Start] key.

#### Note

- ☐ To stop printing, press [Stop Printing]. The display returns to that of step ♣.
- 6 Press [Exit].

#### Note

☐ To print a message in another Personal Box, refer to step ♠, and then try again.

## **7** Press [Exit].


## Information Boxes



Before using this function, set the Information Box in advance. See p.163 "Programming/editing Information Boxes".

#### **Information Boxes**

Use the Information Box function to set up the machine as a Fax Information service or Document Server. By scanning documents into Information Boxes, other parties can receive these messages whenever they request them.




- You can program documents for this function with "Storing Messages in Information Boxes". See p.38 "Storing Messages in Information Boxes".
- For other parties to be able to retrieve a message programmed in an Information Box, you need to inform them of the SEP code assigned to that Information Box.
- When an SEP Code Polling Reception request is made by another party, the SEP code they specify is matched against the SEP codes programmed in that Information Boxes. If a code matches, the message stored in the Information Box is sent to the other party automatically.

- You can check the contents of Information Boxes with "Printing Information Box Messages". See p.40 "Printing Information Box Messages".
- You can set a password for Information Boxes in advance. A password can be set in "Key Operator Setting". See p.163 "Programming/editing Information Boxes".

#### Storing Messages in Information Boxes

Follow these steps to store a message in an Information Box.

- Note
- ☐ One Information Box stores one file.
- ☐ The stored file is not deleted automatically. If you want to delete a stored file, see p.41 "Deleting Information Box Messages".
- 1 Press [Information].



Select [Store/Delete/Print Information Box File.].

## Select the box in which you want to store the file.




#### Note

- ☐ When there are pre-registered files, a file mark is displayed at the end of the Box Name.
- ☐ A message is displayed, when selecting a box with a file stored in it. Press **[Yes]**, when changing the file name. The file stored originally will be overwritten.

#### When a password is required

**1** Enter the password, and then press [OK].



#### Ø Note

- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ To cancel entering a password, press [Cancel]. The display returns to that of step [3].

## 4 Place the original, and then select the scan settings you require.



#### Note

- ☐ You can also select the following settings:
  - Book Fax
  - Two-Sided Original (The optional Auto Document Feeder (ADF) is required.)
  - Stamp (The optional Auto Document Feeder (ADF) is required.)

#### 

p.11 "Placing Originals", Facsimile Reference <Basic Features> p.27 "Scan Settings", Facsimile Reference <Basic Features>

## **5** Press the [Start] key.

The machine starts to scan the original.

To stop scanning, press [Stop Scanning]. The display returns to that of step **2**.

## 6 Press [Exit].

#### 


☐ To store a message in another Information Box, return to step 3.

## Press [Exit].


## **Printing Information Box Messages**

Follow these steps to print a message stored in an Information Box.

1 Press [Information].




- Select [Store/Delete/Print Information Box File.].
- Press [Print File].
- Press [Print File], and select the box that contains the stored file you want to print.



- ☐ You cannot select a box that has no stored file.

#### When a password is required

• Enter the password, and then press [OK].




- Note
- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ To cancel entering a password, press [Cancel]. The display returns to that of step 4.
- Press the [Start] key.
  - **𝚱** Note
  - ☐ If you want two-sided printing (optional), press [Print 2 Sides] before pressing the [Start] key.
  - ☐ To stop printing before pressing the **[Start]** key, press **[Cancel]**. The display returns to that of step **4**.
  - ☐ To stop printing after pressing the **[Start]** key, press **[Stop Printing]**. The display returns to that of step **[]**.
- 6 Press [Exit].
  - Note
  - ☐ Repeat from step ② to print another stored file in the box.
- **7** Press [Exit].


## **Deleting Information Box Messages**

Follow these steps to delete a file stored in an Information Box.

1 Press [Information].




- Select [Store/Delete/Print Information Box File.].
- Press [Delete File].
- 4 Select the box that contains the stored file you want to delete.



When a password is required

• Enter the password, and then press [OK].



#### **𝚱** Note

- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ To cancel entering a password, press [Cancel]. The display returns to that of step 4.
- **5** Press [Delete].
  - Note
  - ☐ To stop deleting, press [Do not Delete]. The display returns to that of step 4.
- 6 Press [Exit].
  - **𝚱** Note
  - ☐ Repeat from step **4** to delete another stored file in another box.
- **7** Press [Exit].

## 4. Other Transmission Features

## **Handy Dialing Functions**

#### **Chain Dial**

This allows you to compose a telephone number from various parts, some of which may be stored in Quick Dials and some of which may be entered using the number keys.

#### Note

- ☐ Maximum length of a telephone or fax number: 128 digits
- ☐ For Memory Transmission and Immediate Transmission, insert a pause between parts of a number. For On Hook Dial and Manual Dial, no pause is needed.

#### (Example) 01133-1-555333

Assume that 01133 is stored in a Quick Dial key.


- 1 Place the original, and then select the scan settings you require.
- Press the Quick Dial key that is programmed "01133".
- 3 Press the [Pause/Redial] key.
- 5 Press the [Start] key.

#### Redial


The machine stores the last 10 destinations dialed. If you want to send a message to a destination which you sent faxes to recently, the Redial function saves you time by finding and entering the number again.

#### Limitation

- ☐ The following kinds of destinations are not stored:
  - Quick Dials
  - Group Dials
  - Destinations dialed as End Receivers for Transfer Request
  - Forwarding terminal of the Substitute Reception
  - Destinations dialed using the external telephone
  - Destinations dialed by Redial (regarded as already stored in memory)
  - Second and later destinations broadcasted to
- ☐ Do not dial any numbers before you press the **[Pause/Redial]** key. If you press the **[Pause/Redial]** key after entering numbers using the number keys, a pause will be entered instead.



2 Select the destination you want to redial to.



#### **𝚱** Note

☐ Now that the date and time the original was read appears as a key, select by pressing it.

4

### **Advanced Features**


#### SUB Code

Normally you can only use Confidential Transmission to send messages to fax machines of the same manufacturer that have the Confidential Reception function. See p.7 "Confidential Transmission". However, if the other machine supports a similar function called "SUB Code", you can send fax messages to the other party using this method instead.


#### Ø Note

- $\Box$  The ID can be up to 20 digits long.
- ☐ You can enter numbers, \*, #, and spaces to program an ID.
- ☐ Make sure the number of digits in the ID matches the specification of the machine to which you are sending.
- ☐ You can store IDs in Destination lists and Programs. See "Registering a Fax Destination", *General Settings Guide*. See p.113 "Registering and Changing Keystroke Programs".
- ☐ Messages you send using this function are marked "SUB" on all reports.
- 1 Place the original, and then select the scan settings you require.
- 2 Dial the fax number using the number keys.

3 Press [Adv. Features].



- 4 Select [SUB Code].
- Press [TX SUB Code].
- **6** Enter a SUB code, and then press [OK].



"SUB Code" appears one line above [Adv. Features] on the display.

#### Note

☐ If you make a mistake, press [Cancel] or the [Clear/Stop] key before pressing [OK], and then try again.

To cancel entering a SUB code, press [Cancel]. The display returns to that of step §.

- **7** To enter a password, press [Password (SID)].
- **8** Enter the password with the number keys, and then press [OK].

- 9 Press [Exit].
- 11 Press the [Start] key.

#### **∅** Note

☐ If you use Immediate Transmission and the fax machine at the destination does not support the SUB Code function, a message will appear on the display to inform you of this. When this happens, press [OK] to cancel the transmission.

#### SID Code

There are times when you may want to use an "SID" (Sender ID) when sending confidential faxes with the SUB Code function.

#### Note

- ☐ The ID can be up to 20 digits long.
- ☐ You can enter numbers, \*, #, and spaces to program an ID.
- ☐ You can store IDs in Destination lists and Programs. See p.113 "Registering and Changing Keystroke Programs". See "Registering a Fax Destination", General Settings Guide.
- ☐ Messages you send using this function are marked "SID" on all reports.

#### **SEP Code**

Normally you can only use Polling Reception to receive faxes from machines that have the Polling Reception function and the same manufacturer. However, if a machine of another manufacturer supports Polling Reception, you can receive fax messages from the other party using this method instead.


You can receive messages that have the same SEP code as the SEP code you entered.

#### Note

- $\Box$  The ID can be up to 20 digits long.
- ☐ Make sure the number of digits in the ID matches the one set on the machine to which you are sending.
- ☐ You can enter numbers, \*, #, and spaces to program an ID.
- ☐ You can store IDs in Destination lists and Programs. See "Registering a Fax Destination", *General Settings Guide*. See p.113 "Registering and Changing Keystroke Programs".
- ☐ Messages you receive using this function are marked "SEP" on all reports.
- 1 Dial the fax number using the number keys.
- 2 Press [Adv. Features].



- 3 Select [SEP Code].
- 4 Press [RX SEP Code].
- Enter a SEP code, and then press [OK].




"SEP Code" appears one line above [Adv. Features] on the display.

#### Ø Note

☐ If you make a mistake, press [Cancel] or the [Clear/Stop] key before pressing [OK], and then try again.


To cancel entering a SEP code, press [Cancel]. The display returns to that of step [4].

- To enter a password, press [Password (PWD)].
- **T** Enter the password using the number keys, and then press [OK].
- 8 Press [Exit].
- **9** Press [Transmission Mode].



1 Select [Polling RX].

Press [Default ID/Free Polling RX], and then press [OK].



[Polling RX] is highlighted, and "Default ID/Free Poll." is shown.

#### **𝚱** Note

- ☐ To cancel Polling RX, press [Cancel]. The display returns to that of step ①.
- Press [OK].

The standby display appears.

Press the [Start] key.

#### **PWD Code**

There are times you may want to use a password when receiving faxes by polling using the SEP Code function.


#### Note

- ☐ The password can be up to 20 digits long.
- ☐ You can enter numbers, \*, #, and spaces as a password.
- ☐ You can store IDs in Destination lists and Programs. See "Registering a Fax Destination", *General Settings Guide*. See p.113 "Registering and Changing Keystroke Programs".
- ☐ Messages you send using this function are marked "PWD" on all reports.

#### **Transfer Request**

Transfer Request allows fax machines that have this function to automatically distribute incoming messages to multiple fax destinations. This function helps you save costs when you send the same message to more than one place in a distant area, and saves time since many messages can be sent in a single operation.

The diagram below may make the concept clearer.



The following terminologies are used in this section:

#### Requesting Party

The machine where the message originates.

#### Transfer Station

The machine that forwards the incoming message to another destination.

#### End Receiver

The final destination of the message or the machine to which the Transfer Station sends to.

#### Preparation

Before you can use this function, you must program the Polling ID and your own fax number. See p.170 "Programming a Polling ID", p.169 "Transfer Report".

#### Limitation

- ☐ The Transfer Stations you specify must be machines of the same manufacturer and have the Transfer Station function.
- ☐ You cannot use Transfer Request without programming the fax number of the Requesting Party in a Quick Dial or Speed Dial.

#### Note

- ☐ Polling ID's of the Requesting Party (this machine) and Transfer Stations must be identical.
- ☐ You can specify up to 500 Transfer Stations in a Transfer Request.
- ☐ You can have up to 30 End Receivers per Transfer Station. If you specify a Transfer Station Group, the Group counts as a single receiver.
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps ② and ⑤.

## 1 Place the original, and then select any scan settings you require.

#### 

p.11 "Placing Originals", Facsimile Reference <Basic Features>

p.27 "Scan Settings", Facsimile Reference <Basic Features>

## 2 Dial a Transfer Station.

#### Note

- ☐ Enter the fax numbers of the Transfer Stations using either the Quick Dial or number keys.
- ☐ If you make a mistake, press the **[Clear/Stop]** key, and then try again.


## 

p.32 "Dialing", Facsimile Reference <Basic Features>

## Press [Adv. Features].



- 4 Select [Transfer Req.].
- **5** Press [Receiving Station].
- 6 Dial an End Receiver.



#### Note

- ☐ You cannot enter End Receiver numbers directly. The numbers must be stored in Destination lists, Speed Dial, or Groups in the Transfer Station(s). To specify an End Receiver, use the procedure described below.
- ☐ To cancel the Transfer Request, press [Cancel]. The display returns to that of step **⑤**.

#### **Destination List**

- Press [# Quick Dial].
- 2 Enter the number of the Destination list where the End Receiver is stored.

For example, to select the number stored in Quick Dial 01 of the Transfer Station, enter: [0][1].

#### Speed Dial

- Press [#★ Speed Dial].
- **2** Enter the number of the Speed Dial code.

For example, to select the number stored in Speed Dial 12 of the Transfer Station, enter: [1][2].

#### **Group Dial**

- Press [#XX Group Dial].
- **2** Enter the number of the Group number.

For example, to select the number stored in Group Dial 04 of the Transfer Station, enter: [0][4].

- **7** To specify another End Receiver, press [Add].
  - Note
  - □ Press [▲ Prev.] or [▼ Next] to see the End Receivers already entered. You can select an End Receiver from this list and remove it by pressing [Clear] or the [Clear/Stop] key.
- When you have specified all the End Receivers, press [OK].
- Press [Exit].



The Transfer Stations and End Receivers are displayed.

Press the [Start] key.

## With Transfer Requests set in the System Settings


You can program a Quick Dial key with Transfer Station and/or End Receiver using the Transfer Request function in the System Settings. See the *General Settings Guide*.

1 Place the original down, and then select the desired settings.

#### 

p.11 "Placing Originals", Facsimile Reference <Basic Features> p.27 "Scan Settings", Facsimile Reference <Basic Features>

**2** Press the key programmed with Transfer Request.



3 Press the [Start] key.

## Setting Multistep Transfer

Register a Transfer Station in a Destination list. When receiving a transfer request that specifies the same End Receiver as programmed in the Destination list, this machine sends a transfer request to the programmed Transfer Station. This function allows fax messages to be transferred via multiple stations and makes fax message transfer more efficient.

You can program up to 30 End Receivers per Transfer Station. For more information, contact your service representative.

### On Hook Dial

This is just like using the external telephone, except you do not have to pick up the external telephone before dialing. Just press the **[On Hook Dial]** key and dial the number. If you hear a voice, you can pick up the external telephone and speak with the other party.

#### Limitation

☐ This function is unavailable for the optional extra G3 interface unit.


#### Ø Note

- ☐ This function is unavailable in some countries.
- 1 Place the original, and then select the scan settings you require.

#### 

p.11 "Placing Originals", Facsimile Reference <Basic Features> p.27 "Scan Settings", Facsimile Reference <Basic Features>

2 Press the [On Hook Dial] key.




You will hear a low tone from the internal speaker.

#### **𝒯** Note

☐ If you want to cancel this operation, press the **[On Hook Dial]** key again.

## 3 Dial.



The machine immediately dials the destination.

#### **∅** Note

- ☐ You can adjust the volume of the On-hook sound by pressing [Higher] or [Lower] in the upper right-hand corner of the display. The volume can also be preprogrammed in "General Settings and Adjustments". See p.47 "Adjusting the Volume", Facsimile Reference <Basic Features>.
- ☐ If you make a mistake, press the **[On Hook Dial]** or **[Clear Modes]** key, and then return to step **2**.
- When the line is connected and you hear a high-pitched tone, press the [Start] key.

#### Note

- ☐ If you hear a voice, pick up the external telephone before you press the **[Start]** key and notify the receiver that you want to send a fax message (ask them to switch to facsimile mode).
- ☐ After transmission, the machine returns to standby mode.
- ☐ If you want to cancel a transmission, press the **[Clear/Stop]** key, and then remove the originals.

## **Manual Dial**

The external telephone is required.

Pick up the handset of the external telephone and dial. When the line is connected and you hear a high-pitched tone, press the **[Start]** key to send your fax message. If, on the other hand, you hear a voice at the other end, continue conversation as normal.

#### Limitation

- ☐ This function is unavailable for the optional extra G3 interface unit.
- ☐ The result of a transmission with Manual Dial is not mentioned in the Transmission Result Report (Immediate Transmission).
- 1 Place the original, and then select the scan settings you require.

#### 

p.11 "Placing Originals", Facsimile Reference <Basic Features> p.27 "Scan Settings", Facsimile Reference <Basic Features>

**2** Pick up the external telephone.

You will hear a tone.

3 Dial.



The machine immediately dials the destination.

#### Note

- ☐ If you make a mistake, replace the external telephone, and then try again from step ②.
- When the line is connected and you hear a high-pitched tone, press the [Start] key to send your fax message.

#### Ø Note

- ☐ If you hear a voice, tell the receiver that you want to send them a fax message (ask them to switch to facsimile mode).
- **5** Replace the handset of the external telephone.

After transmission, the standby display appears.

#### 

☐ If you want to cancel a transmission, press the **[Clear/Stop]** key, and then remove the originals.

## **Changing the Line Port**

The optional extra G3 interface unit is required.


When the extra G3 interface unit is installed, you can connect to a maximum of three ports.

#### Ø Note

- ☐ When you install the extra G3 interface unit, you can specify the line port home position from "Gen. Settings/Adjust". See p.130 "General Settings/Adjustment".
- ☐ When sending a fax, you can select the line port if dialing with the number keys or Chain Dial.

#### **❖** G3

G3 is selected after power up or when the machine is reset. If you install the extra G3 interface unit, you can select "G3-1", "G3-2", "G3-3", or "G3-Auto" depending on the number of the installed unit.



#### ♦ Multi-port

When the extra G3 interface unit is installed, communications can take place simultaneously through two lines at once.


The following list shows protocol combinations available for each line type.

Option	Available line types	Available protocol combinations
Without option	PSTN	G3
Extra G3 interface unit	PSTN+PS TN	G3+G3
Extra G3 interface unit	PSTN+PS TN+PSTN	G3+G3+G3
+ Extra G3 interface unit		

#### Ø Note


- ☐ A maximum of three communications can take place simultaneously.
- ☐ You cannot perform three Immediate Transmissions simultaneously.
- ☐ If three communications are in progress, the display shows the first communication that was initiated.

## 1 Press [Select Line].




## **2** Select the line you want to use.

When one optional extra G3 unit is installed.



When two optional extra G3 units are installed.




#### Note

- ☐ If you select "G3 Auto", the machine will use any available line. This increases efficiency.
- Press [Exit].

### **Sub Transmission Mode**

#### **Book Fax**

Use to send book originals from the exposure glass. Pages are scanned in the order shown below.



#### Limitation

- ☐ Place the original on the exposure glass. You cannot use the optional Auto Document Feeder (ADF).
- ☐ Depending on paper sizes available in the destination machine, the message may be reduced when printed at the other end.


#### Ø Note

- ☐ You can have bound originals scanned as left or right page first. You can set which page (left or right) the machine scans first as default with the User Parameters. See p.147 "Changing the User Parameters" (switch 06, bit 6).
- 1 Place the original on the exposure glass, and then select the scan settings you require.


#### **₽** Reference

p.11 "Placing Originals", Facsimile Reference <Basic Features> p.27 "Scan Settings", Facsimile Reference <Basic Features>

## 2 Press [Sub TX Mode].




- 3 Select [Book Fax].
- 4 Select the size of the original.



#### Note

- ☐ To cancel this mode, press [Cancel]. The display returns to that of step [3].
- ☐ If you select A3, the original will be sent using Image Rotation Transmission. See p.73 "Transmission with Image Rotation".
- Select [From first Page] or [From second Page], and then press [OK].



The selected original size is shown above the highlighted [Book Fax].

#### Note

- ☐ Select [From first Page] to send a book original from the first page.
- ☐ Select [From second Page] if you want to send a cover letter as the first page.
- 6 Press [OK].
- Dial, and then press the [Start] key.

#### **𝚱** Note

- ☐ When sending more than one page, place the originals individually, one after the other, pressing the [Start] key after each page.
- ☐ After the last original has been scanned, press [#].
- ☐ If [♠] is not pressed, the machine will automatically start sending the documents, 60 seconds after the last original has been scanned.

## Two-Sided Transmission (Double-Sided Transmission)


The optional Auto Document Feeder (ADF) is required.

Use this function to send two-sided originals.


#### 

☐ Originals placed on the exposure glass cannot be sent.

☐ The front and back of the scanned original will be printed in order on separate sheets at the other end. The orientation of alternate sheets may be reversed at the other end. If you want to print the original with the same orientation at the other end, specify the "Original Position" and "Page Opening Orientation".



GHPY020



GHPY030


- ☐ This function is only available with Memory Transmission.
- ☐ This function is only available with the ADF.
- ☐ You can confirm whether both sides were properly scanned using the Stamp function. See p.66 "Stamp".

- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps ② and ⑤.
- 1 Place the original in the ADF, and then select the scan settings you require.

### 


p.11 "Placing Originals", Facsimile Reference <Basic Features> p.27 "Scan Settings", Facsimile Reference <Basic Features>

Press [Sub TX Mode].




- 3 Select [2 Sided Original].
- **4** Specify the original position.

Check the orientation of the placed document, and then press recommendation or result.




- Note
- ☐ Make sure that the specified original position matches the orientation of originals loaded in the ADF.

Specify the page opening orientation from [Top to Top] or [Top to Bottom].



Specify the transmission mode from [2 Sided from 1st Page] or [1 Sided for 1st Page], and then press [OK].



The selected original position and page opening orientation are shown above the highlighted [2 Sided Original].

- Note
- ☐ To cancel this mode, press [Cancel]. The display returns to that of step 3.
- ☐ Select [2 Sided from 1st Page] to send a two-sided original from the first page.
- ☐ Select [1 Sided for 1st Page] if you want to send a cover letter as the first page.
- 7 Press [OK].
- Dial, and then press the [Start] key.

### **Standard Message Stamp**

Use this function to stamp a standard message at the top of the first original sent.

There are four types of standard messages: "Confidential", "Urgent", "Please phone", and "Copy to corres. section"

You can also program other messages.


#### 

- ☐ While this function is in use, the third line of the Label Insertion is not printed. See p.70 "Programming the Label Insertion".
- ☐ When there is an image around the area where the standard message is to be stamped, that image is deleted.
- ☐ To program a standard message, use the Program/Change/Delete Standard Message function. See p.137 "Programming, Changing, and Deleting Standard Messages".
- 1 Place the originals, and the select the scan settings you require.


#### **₽** Reference

p.11 "Placing Originals", Facsimile Reference <Basic Features> p.27 "Scan Settings", Facsimile Reference <Basic Features>

## 2 Press [Sub TX Mode].



- 3 Select [Std. Message].
- 4 Select the standard message to be stamped, and then press [OK].



The selected standard message is shown above the highlighted [Std. Message].

#### Ø Note

- ☐ To cancel the selection, press **[Cancel]**. The display returns to that of step **[3**.
- ☐ Programmed standard messages are shown in the keys.
- ☐ The machine cannot stamp multiple standard messages.
- Press [OK].
- **6** Dial, and then press the **[Start]** key.

### **Sending an Auto Document**

If you often send a particular page to people (for example a map, a standard attachment, or a set of instructions), store that page in memory as an Auto Document. This saves rescanning every time you want to send it.

You can fax an Auto Document by itself, or attach it to a normal fax message.

#### Preparation

You need to register an Auto Document. See p.138 "Storing, Changing, and Deleting an Auto Document".

#### Note

- ☐ You can attach one Auto Document to each transmission.
- ☐ You can store up to 6 Auto Documents (up to 18 with the optional expansion memory installed). See p.138 "Storing, Changing, and Deleting an Auto Document".
- ☐ Files with Auto Documents are sent by Memory Transmission.
- ☐ When sending an Auto Document with other files, the Auto Document is sent first.
- ☐ Storing Auto Documents reduces the amount of free memory slightly. Unless you delete the document, free memory will not return to 100%.
- ☐ You can print an Auto Document currently stored in memory. See p.60 "Printing documents stored as Auto Documents".
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps ② and ⑤.


## 1 Place the original, and then select the scan settings you require.

#### 

p.11 "Placing Originals", Facsimile Reference <Basic Features> p.27 "Scan Settings", Facsimile Reference <Basic Features>


#### 

- ☐ When you fax an Auto Document, start from step ②2.
- Press [Sub TX Mode].



- 3 Select [Auto Document].
- A Select an Auto Document file, and then press [OK].

When you fax an Auto Document by itself, press [TX Stored File(AD) Only], and then press [OK].



The selected file name is shown above the highlighted [Auto Document].


#### Note

- ☐ Programmed Auto Documents are shown in the keys.
- ☐ If you make a mistake, press [Clear] or the [Clear/Stop] key before pressing [OK], and then try again.
- ☐ To cancel the Auto Document, press [Cancel]. The display returns to that of step 3.
- Press [OK].
- 6 Dial, and then press the [Start] key.

## Printing documents stored as Auto Documents


This function is used for printing documents stored as Auto Documents. This function is very convenient as it can be used for checking the contents of stored files.

1 Press [Sub TX Mode].



2 Select [Auto Document].

Select an Auto Document file to be printed, and then press [Print File].



- Note
- ☐ To cancel the Auto Document, press [Cancel] before pressing [Print File]. The display returns to that of step ②.
- 4 Press the [Start] key.

Once printing is completed, the display returns to that of step **3**.


- Note
- ☐ To cancel printing, press [Cancel]. The display returns to that of step [3].
- Press [Cancel].

  - ☐ You can also send Auto Documents. See p.59 "Sending an Auto Document".
- 6 Press [OK].

# Sending a Stored File

Use this function to send documents stored in the Document Server. You can specify and send multiple documents, and also send them with scanned originals all at once.

You can also print stored originals with **[Print File]**. See p.64 "Printing stored documents".



# Preparation

Store the documents to be sent in advance. You can program a password for this function. You can change the user names, file names, and passwords of stored documents. See p.117 "Using the Document Server", and p.120 "File Manage".

# Note

- ☐ Received fax documents are stored and categorized as "Stored RX Files". See p.30 "Printing/Deleting Received and Stored Documents (Printing Stored RX File)".
- ☐ You can program one of the Quick Operation keys with operations for this function. Using the key allows you to omit steps **1** and **2**.

#### Sending stored documents

The machine sends documents stored in the Document Server.


The documents stored in the Document Server can be sent again and again until they are deleted. Once sent, documents are stored in the Document Server. Therefore, you can send them in just one operation without having to set your originals again.

#### Limitation


- ☐ You cannot use the following transmission methods:
  - Free Polling Transmission
  - Default ID Transmission
  - ID Override Transmission
  - Immediate Transmission
  - Parallel Memory Transmission
  - On Hook Dial
  - Manual Dial

- ☐ Only documents stored using the facsimile function can be sent. Documents stored using the copy , printer or scanner functions cannot be sent.
- ☐ You can specify and print multiple documents. You can specify a maximum of 30 documents at once.
- ☐ The machine can send a total of 1,000 pages in one operation.
- ☐ The specified documents are sent with the scan settings made when they were stored.

# 1 Press [Sub TX Mode].



- 2 Select [Select Stored File].
- **3** Select the documents to be sent.



#### Note


- ☐ When multiple documents are selected, they are sent in the order of selection.
- ☐ Press [**TX Order**] to arrange the order of the documents to be sent.
- ☐ Press [File Name] to place the documents in alphabetical order.
- ☐ Press [User Name] to place the documents in order by registered user name.
- ☐ Press [Date] to place the documents in order of registered date.

Specifying documents from the file list


- Press [▲ Prev.] or [▼ Next] to display the documents to be sent.
- 2 Select the file name.

Specifying documents from the User Name

• Press [Search by User Name].




Select the user name of the registered document, and then press [OK].




- Note
- ☐ To search by user name, press [Non-programed Name], and then enter the user name. Partial matching is used when searching for a user name.
- **3** Select the file name to be sent.

Specifying documents from the file name

• Press [Search by File Name].




2 Enter the name of the document to be sent, and then press [OK].




# Note

- ☐ Partial matching is used when searching for a file name.
- **3** Select the file name to be sent, and then press [OK].
- If you select a document with a password, enter the password, and then press [OK].



If the document does not have a password, proceed to step **5**.

When you want to add your originals to stored documents and send them all at once, press [ Origi. + Stored File] or [Stored file + Origi.].



When sending only stored documents, proceed to step **6**.

#### 

- ☐ When [☐ Origi. + Stored File] is pressed, the machine sends the originals and then stored files. When [Stored file + ☐ Origi.] is pressed, the machine sends the stored files and then originals.
- ☐ The added originals are not stored.
- 6 Press [OK] twice.

# **∅** Note


- ☐ To add an original to stored documents, place the original, and then select any scan settings you require.
- Dial, and then press the [Start] key.

#### **Printing stored documents**


Use this function to print documents stored in the Document Server.

#### Note

- ☐ Only documents stored using the facsimile function can be printed.
- ☐ You can print documents saved from the copy or the printer function with the Document Server. You cannot print documents saved from the scanner function with this mode.
- You can also print the first page only to check the content of the original.
- ☐ You can specify and print multiple documents. You can specify a maximum of 30 documents at one time.
- 1 Press [Sub TX Mode].




- 2 Select [Select Stored File].
- 3 Select the document to be printed.



#### Note

- ☐ The documents stored using the facsimile function appear on the display.
- ☐ Press [File Name] to place the documents in alphabetical order.
- ☐ Press [User Name] to place documents in order of registered user name.
- ☐ Press [Date] to place the documents in order by the programmed date.
- ☐ To see details of the selected document, press [Detail]. To return to the standby menu, press [File List].




Selecting a document from file list


- Press [▲ Prev.] or [▼ Next] to display the document to be sent.
- 2 Select the file name.

Specifying a document from the User Name

1 Press [Search by User Name].



2 Press the user name of the document to be sent, and then press [OK].



# Note

☐ To search by user name, press [Non-programed Name], and then enter the user name. User name serches using partial matching.


# **₽** Reference

"Entering Text", General Settings Guide


3 Select the file name.

Specifying a document from the file name

1 Press [Search by File Name].




2 Enter the file name to be printed, and then press [OK].



- Ø Note
- ☐ Partial matching is used to search for the file name.

"Entering Text", General Settings Guide

- 3 Select the file name.
- If you select a document with a password, enter the password, and then press [OK].



If the document does not have a password, proceed to step **5**.

# **5** Press [Print File] or [Print 1st Page].

When [Print File] is pressed, the machine prints all the pages. When [Print 1st Page] is pressed, the machine prints only the first page.

#### Limitation

- ☐ When [Print 1st Page] is selected, originals larger than A4 size are printed after they are reduced to A4 size.
- ☐ The machine can print up to 30 files using the Print 1st Page function.

### **𝚱** Note

☐ To print both sides, press [Print 2 Sides].

# 6 Press the [Start] key.

### Note

- ☐ When only the first page is printed, the file name is printed at the top of the paper.
- ☐ To cancel printing, press [Cancel].

# **7** Press [Exit].

# Note

☐ You can also send a stored document. See p.61 "Sending stored documents".


# 8 Press [OK].

The standby display appears.

# **Stamp**

The optional Auto Document Feeder (ADF) is required.

When sending a fax message using the ADF, the machine can stamp a circle mark at the bottom of the original. When sending a two-sided document, the document is marked at the bottom of the front page and top of the rear page. This stamp indicates that the original has been successfully stored in memory for Memory Transmission, or successfully sent by Immediate Transmission.




- ☐ Stamp only works when scanning from the ADF.
- ☐ When the stamp starts getting lighter, replace the cartridge. See p.177 "Replacing the Stamp Cartridge".
- ☐ If a page was not stamped even though the Stamp function is turned on, you need to resend that page.

- ☐ If you use this function often, you can set the default in "General Settings/Adjustment" so that this function is always on. In this case, Stamp can easily be turned off for any single transmission by pressing [Stamp]. See p.130 "General Settings/Adjustment". A paper jam during Parallel Memory Transmission may cause the transmission to be failed even if stamping is performed.
- ☐ You cannot turn the Stamp function on or off while a document is being scanned.
- 1 Place the original, and then select the scan settings you require.

# 

p.11 "Placing Originals", Facsimile Reference <Basic Features> p.27 "Scan Settings", Facsimile Reference <Basic Features>

2 Press [Sub TX Mode].



- Select [Stamp], and then press [OK].
  - Note
  - ☐ To cancel the stamp, press [Stamp] again before pressing [OK].
- Dial, and then press the [Start] key.

# **Transmission Options**

This section describes various functions that you can switch on and off for any particular transmission, following the procedures given here.

In addition, if you frequently use a certain option configuration, you can change the default home position (on or off) of each option.

#### **Fax Header Print**

In some cases, you may want the other party to receive an unmarked copy of your original. To do this, switch Fax Header off.

When the Fax Header is set to "ON", the stored name is printed on the receiver's paper.

You can store two Fax Headers; "First Name" and "Second Name".

For example, if you store your department name in one and your organization name in the other, you could use the first when sending internal faxes and the second for external faxes.

- ☐ If you used the number keys to specify the receiver, the first header name will be printed on the receiver's paper.
- ☐ You can program fax header names using the Program Fax Information function.
- ☐ You can select whether or not dates, fax header names, file numbers, or page numbers are printed by changing their respective user parameters.
- ☐ You can program one of the Quick Operation keys with operations for this function.

#### **Label Insertion**

With this function you can have the receiver name printed on the message when it is received at the other end. The name will be printed at the top of the page and will be preceded by "To". You can also cause the text programmed as a standard message to be printed. See p.137 "Programming, Changing, and Deleting Standard Messages".

## **𝚱** Note

- When there is an image around the area where the Label is to be printed, that image is deleted.
- ☐ You can program one of the Quick Operation keys with operations for this function.

#### Sender Stamp


When there is data, such as the user name and department name, programmed into the user code, you can have the machine print a sender stamp on the right edge of your paper.

# **𝚱** Note

☐ Enter the user name in System Settings.

#### **Reduced Image Transmission**

Using this function, your message is sent at a reduced size (93%) with a blank margin on the left.




### Note

- ☐ This function is unavailable with Immediate Transmission, or specified transmission of a stored document.
- ☐ Image Rotation is unavailable with this function.


#### **Auto Reduce**

When this function is turned on, if the receiver's paper is smaller than the paper you are sending on, the message is automatically reduced to fit onto the paper available at the other end.



# **∰**Important

☐ If you turn this function off, the scale of the original is maintained and some parts of the image may be deleted when printed at the other end.



#### **Default ID Transmission**

If you turn this function on, transmission will only take place if the destination's Polling ID is the same as yours. This function can stop you accidentally sending information to the wrong place (you need to coordinate Polling ID's with the other party).

#### Ø Note


You can program one of the Quick Operation keys with operations for this function.

# Selecting transmission options for a single transmission

1 Place the original, and then select the scan settings you require.


# **₽** Reference

p.11 "Placing Originals", Facsimile Reference <Basic Features> p.27 "Scan Settings", Facsimile Reference <Basic Features> Press [Sub TX Mode].



- 3 Select [Options].
- 4 Select options to be set up.





# Ø Note

☐ To close the option settings, proceed to step **⑤**.

# Programming the Fax Header Print

• Press [ON] to specify the fax header print.

# Note

☐ Press [OFF] if you do not want to print the sender name.

#### Programming the Label Insertion


• Press [Programed Name] in "Label Insertion".



☐ Press **[OFF]** if you do not want to insert a destination.

Programming the Stamp Sender Name

- 1 Press [Change].
- 2 Press the name of the user to be stamped, and then press [OK].



# Ø Note

- ☐ The set user name is displayed when the user code has been stored. See the *General Settings Guide*.
- ☐ You can switch titles by pressing the title keys.
- ☐ To stamp a non-registered user name, press [Non-programed Name], and then enter the user name.
- ☐ If you do not want to stamp the sender's stamp, press [No Stamp].

# Programming the Reduced Image Transmission

• Press [ON] in "Reduced Image TX".



☐ Press **[0FF]** if you do not want to do a reduced transmission.

### Programming the Auto Reduce

• Press [ON] in "Auto Reduce".



☐ Press **[OFF]** if you do not want to use the Auto Reduce function.

# Programming the Default ID Transmission

• Press [ON] in "Default ID TX".

- ☐ Press **[OFF]** if you do not want to use ID transmission.
- **5** Press [OK] twice.
- 6 Set the destination, and then press the [Start] key.

# **More Transmission Functions**

# If Memory Runs Out While Storing an Original

If you run out of memory while storing an original (free space reaches 0%), the message "Memory is full. Cannot scan more. Transmission will be stopped." is displayed.

Press **[Exit]** to transmit stored pages only.

# **𝒯** Note

☐ In default, scanned pages are sent. To change the settings to delete scanned pages, contact your service representative.

# **Parallel Memory Transmission**

This function dials while the original is being scanned. Standard Memory Transmission stores the original in memory, then dials the destination. Parallel Memory Transmission allows you to quickly determine whether a connection was made. In addition, this function scans the original faster than Immediate Transmission. This is useful when you are in a hurry and need to use the original for another purpose.

# **?** Limitation

- ☐ Standard Memory Transmission is used instead of Parallel Memory Transmission in the following cases:
  - When the line is busy and could not be connected to
  - With Send Later

- When you store an original for Memory Transmission while another communication is in progress
- When two or more destinations are specified
- When you send only an Auto Document
- When the first page of an original is placed on the exposure glass
- When you send messages stored in the Document Server

- ☐ You can turn this function on or off with the User Parameters. See p.147 "Changing the User Parameters" (switch 07, bit 2).
- ☐ Standard Memory Transmission may be used instead of Parallel Memory Transmission depending on the optional equipment installed if there is not enough free memory left.
- ☐ If you use this function, the Memory Storage Report will not be printed.
- ☐ If the **[Clear/Stop]** key is pressed, an original will jam or memory will run out during Parallel Memory Transmission stops. The Transmission Result Report is printed and files are deleted.
- ☐ When Parallel Memory Transmission is used, the total number of originals in "Fax Header Print" is not automatically printed.

# **Checking the Transmission Result**

- Turn the Transmission Result Report on if you want a report to be printed after every successful transmission. See p.18 "Memory Transmission", Facsimile Reference <Basic Features>.
- If you leave the Transmission Result Report off, the report will not be printed after every transmission. However, if a transmission fails, a Communication Failure Report will be printed instead. See p.75 "Communication Failure Report".
- You can also check the transmission result by examining the Journal. See p.23 "Printing the Journal".
- You can either print or scroll through the Journal on the display. See p.27 "Checking the Transmission Result (TX File Status)".

# **Automatic Redial**

If a fax message could not be transmitted because the line was busy or an error occurred during transmission, redialing is done five times in five minutes intervals (these figures vary according to which country you are in).

If redialing fails after four redials, the machine cancels the transmission and prints a Transmission Result Report or Communication Failure Report.

# **Batch Transmission**

If you send a fax message by Memory Transmission and there is another fax message waiting in memory to be sent to the same destination, that message is sent along with your original. Several fax messages can be sent with a single call, thus eliminating the need for several separate calls. This helps save communication costs and reduce transmission time.

Fax messages for which the transmission time has been set in advance are sent by batch transmission when that time is reached.

### Note

- ☐ You can turn this function on or off with the User Parameters. See p.147 "Changing the User Parameters" (switch 14, bit 2).
- ☐ The originals to be transmitted at a specific time will be sent at that time.
- ☐ If fax memory is overloaded, messages may not be sent in the order they were scanned.

# **ECM (Error Correction Mode)**

This function automatically sends data that was not transmitted successfully using a system that complies with international standards.

ECM requires that the destination machine has the same function.



☐ You can turn this function on or off using the Key Operator Settings. See p.146 "ECM".

# **Broadcasting Sequence**

If you dial several destinations for the same message (broadcasting), the messages are sent in the order in which they were dialed. If the fax message could not be transmitted, the machine redials that destination after the last destination specified for broadcasting. For example, if you specify four destinations, A through D, for broadcasting, and if the lines to destinations A and C are busy, the machine dials the destinations in the following order: A, B, C, D, A, and C.

# **Checking the Transmission Progress**

To check which destinations the fax message has been sent to so far, print the TX file list.

# **Dual Access**

The machine can scan other messages into memory even while sending a fax message from memory, receiving a message into memory, or automatically printing a report. Since the machine starts sending the second message immediately after the current transmission ends, the line is used efficiently.

# Note

☐ Note that during Immediate Transmission or when in User Tools mode, the machine cannot scan an original.

# Transmission with Image Rotation

Generally, place A4,  $8^1/2$ "×11" originals in the landscape orientation ( $\square$ ). If you place an A4,  $8^1/2$ "×11" original in the portrait orientation ( $\square$ ), the image will be sent rotated by 90°. Providing the receiver has A4,  $8^1/2$ "×11" landscape paper ( $\square$ ), the message will be printed the same size as the original.

#### **𝚱** Note

- ☐ This function is unavailable with Immediate Transmission.
- ☐ When Image Rotation is used, all messages are sent by normal Memory Transmission.
- ☐ This function is unavailable when using Mixed Original Sizes.


# Simultaneous Broadcast

The optional extra G3 interface unit is required.

The Standard Broadcast function sends faxes one at a time to multiple destinations in the order of specified destination numbers.

The Simultaneous Broadcast function, however, can simultaneously send faxes to three destinations using different lines.

This results in a shorter overall transmission time.



#### Note

- ☐ This function can use a maximum of three lines simultaneously.
- □ When using the optional extra G3 interface unit, if you set the line selection as "G3 Auto" beforehand, the machine will use whichever G3 line is not busy. This increases efficiency.

# **JBIG Transmission**

The optional fax function upgrade unit is required.

If you use JBIG (Joint Bi-level Image Experts Group) compression, you can send photographic originals faster than with other methods of compression. You can only use this function with G3 line type.

### Limitation

☐ This function requires that the other party's fax machine has both the JBIG function and ECM function (G3 communication only).

- ☐ When the optional extra G3 interface unit is installed, JBIG receptions of G3-2 and G3-3 lines are standard.
- ☐ If ECM is turned off, JBIG Transmission is unavailable. See p.146 "ECM".

# **Printed Report**

# **Memory Storage Report**

This report is printed after an original is stored in memory. It helps you review the contents and the destinations of stored originals. Even if the machine is set up not to print this report, it is still printed if an original could not be stored.

#### **∅** Note

- ☐ You can turn this report on and off. See p.147 "Changing the User Parameters" (switch 03, bit 2).
- ☐ You can select whether to include part of the original image on the report. See p.147 "Changing the User Parameters" (switch 04, bit 7).
- ☐ If you use Parallel Memory Transmission, the Memory Storage Report is not printed.

# Transmission Result Report (Memory Transmission)

This report is printed when a Memory Transmission is completed, so you can check the result of the transmission. If two or more destinations are specified, this report is printed after the fax message has been sent to all the destinations. If the machine is set up not to print this report and the fax message could not be successfully transmitted, a Communication Failure Report is printed. See p.75 "Communication Failure Report".

#### Note

- ☐ You can turn this function on or off with the User Parameters. See p.147 "Changing the User Parameters" (switch 03, bit 0).
- ☐ You can select whether to include part of the original image on the report. See p.147 "Changing the User Parameters" (switch 04, bit 7).
- ☐ The Page column gives the total number of pages. The Not Sent column gives the number of pages that could not be sent successfully.

# **Communication Failure Report**

This report is only printed if the Transmission Result Report is turned off and a message could not be successfully transmitted with Memory Transmission. Use it to keep a record of failed transmissions so you can send them again.

- ☐ You can select whether to include part of the original image on the report. See p.147 "Changing the User Parameters" (switch 04, bit 7).
- ☐ The Page column gives the total number of pages. The Not Sent column gives the number of pages that could not be sent successfully.

# **Transmission Result Report** (Immediate Transmission)

If you turn this report on, a report will be printed after every Immediate Transmission so you have a record of whether the transmission was successful or not. If the machine is set up not to print this report and the fax message could not be successfully transmitted, the Error Report is printed instead.

# **𝒯** Note


- ☐ You can switch this report on or off in the User Parameters. See p.147 "Changing the User Parameters" (switch 03, bit 5).
- ☐ If the page was sent successfully, the Page column gives the total number of pages sent successfully.

# 5. Reception Features

# Reception

# **Immediate Reception**

Each page of a fax message is printed as soon as it is received. This method is used for standard fax messages.



Normally this machine receives messages by Immediate Transmission. But Memory Reception is used when "Combine 2 Originals", "Multi-copy reception", "Reverse Order Printing reception" or "Two-sided Printing" is set to "ON". See p.84 "Printing Options". If the conditions are that Substitute Reception should be used, a fax message is not printed. It will be stored in memory. See p.77 "Memory Reception". See p.79 "Substitute Reception".

# **𝚱** Note


- ☐ The machine may not be able to receive fax messages when free memory space is low.
- ☐ If free memory reaches 0% during Immediate Reception, any further reception becomes impossible and the current communication is terminated.

# Reception resolution

This machine supports Standard, Detail, and Super fine resolutions for reception. If you do not have the optional fax function upgrade unit, faxes sent at Super fine resolution will be printed on your machine at Detail resolution. This may differ from the sender's intended resolution.

# **Memory Reception**

The machine waits until all pages of the message have been received into memory before printing it.



This method is used with the following functions:

- Combine 2 originals
   See p.87 "Combine Two Originals".
- Multi-copy when set to multiple copies
   See p.86 "Multi-copy Reception".
- Reverse Order Printing See p.88 "Reverse Order Printing".
- 2-sided Printing See p.85 "Two-Sided Printing".

# **∰**Important

- □ When about one hour passes after power to the machine is turned off, all fax messages stored in memory will be lost. If any messages have been lost for this reason, a Power Failure Report is automatically printed when the operation switch is turned on. Use this report to identify lost messages.
- ☐ The machine may not be able to receive large numbers of messages or messages with high data content. In such cases, we recommend you switch off the above functions or install the optional expansion memory.

### Limitation

☐ The machine may not be able to receive fax messages when free memory space is low.

### Ø Note


- ☐ If the free memory space reaches 0% during Memory Reception, the machine can no longer receive the current fax message and stops communicating.
- ☐ If you have selected [Store] for [Reception File Setting], received messages will be saved on the hard disk and will not be printed. You can print those messages by operating the machine or a connected computer, as necessary. See p.172 "Storing or Printing Received Documents".

# **Substitute Reception**

In Substitute Reception, a received fax message is stored in memory instead of being printed. Substitute Reception gets used when the machine cannot print any fax messages. Fax messages received using Substitute Reception are automatically printed when the condition which caused the machine to use Substitute Reception is rectified.

Depending on why the machine cannot print, Substitute Reception might be used for all fax messages received, or for only those messages that match a specified condition.

The Receive File indicator lights to let you know when fax messages have been received using Substitute Reception.



#### **𝚱** Note

- ☐ Reception may not take place if there is not enough free memory.
- ☐ If free memory reaches 0% during Substitute Reception, any further reception becomes impossible and the current communication is terminated.
- ☐ When a fax message is received after **[Store]** has been selected for **[Reception File Setting]** in the Facsimile Features menu, the Receive File indicator lights.

# Receiving messages unconditionally

If one of the conditions listed below occurs, the machine receives all fax messages using Substitute Reception.

Problems	Causes	Solutions
%∕r is lit.	Paper is jammed.	Remove the jammed paper. See " <b>%</b> Cleaning Misfeeds", General Settings Guide.
The machine is printing with other function.	The machine is busy printing with other function.	The message will be automatically printed after the current job finishes.
The message "Following output tray is full. Remove paper." appears.	The output tray is full.	Remove paper from the output tray.
[⁴ is lit.	The cover is open.	Close the cover shown in the display.

#### Receiving messages according to parameter-specified settings

If one of the conditions listed below occurs, the machine receives only those messages that match the conditions specified in the User Parameters. See p.147 "Changing the User Parameters" (switch 05, bit 2,1).

Problems	Causes	Solutions
<b>≛</b> is lit.	All trays out of paper.	Add paper. See " <b>≜</b> Loading Paper", General Settings Guide.
is lit.	Toner is empty.	Replace the toner cartridge. See "La Adding Toner", General Settings Guide.
The message "This tray is out of order." appears.	All trays out of action.	Call your service representative.

You can specify the following conditions with the User Parameters. See p.147 "Changing the User Parameters" (switch 05, bit 2,1).

#### When Own Name or Own Fax Number is received

The machine switches to Substitute Reception only when the sender has programmed their Own Name or Own Fax Number. If the power is switched off for more than an hour, all the messages stored in memory are deleted. In that case, the Power Failure Report or the Journal can be used to identify which messages are lost so you can ask the senders to transmit them again.

# ∰Important

☐ If a sender has not programmed their Own Name or Own Fax Number, the machine may fail to receive an important fax message. We recommend that you ask important senders to program an Own Name or Own Fax Number in advance.

#### Free

The machine switches to Substitute Reception regardless of whether or not the sender has programmed their Own Name or Own Fax Number.

### Polling ID match

The machine switches to Substitute Reception only when the programmed Polling ID of the other end matches the ID of this machine.


#### Disable

The machine does not receive any messages.

# **Reception Functions**

#### **Transfer Station**

Transfer Stations allow you to expand the standard functions of your fax machine to set up complex networks. The diagram below may make the concept clearer.



The following terminologies are used in this section:

# ❖ Requesting Party

The machine where the message originates.

# Transfer Station (this machine)

The machine that forwards the incoming message to another destination.

#### End Receiver

The final destination of the message, that is the machine the Transfer Station sends to. End Receivers must be programmed into a Quick Dial or Groups in the Transfer Station.

#### Limitation

- ☐ Polling ID's of the Requesting Party and Transfer Station must be identical for this function to work.
- ☐ A Transfer Request cannot be sent if the fax number of the transfer station (this machine) is not programmed as a Quick Dial.
- ☐ If your line number is not registered at the Transfer Station, reception will not take place. See p.169 "Transfer Report".
- ☐ If the Requesting Party specifies a Group for the End Receivers and the total number of End Receivers exceeds 500, the Transfer Station cannot transfer the message and sends a Transfer Result Report to the Requesting Party.
- ☐ See "Registering Destination to a Group", *General Settings Guide*.

# Q Multistep transfer

The principles of Transfer Stations can be used to build up a multi-step facsimile network where messages are passed through several Transfer Stations. By programming the End Receivers in a Transfer Station Group, you can enable this machine to transfer messages onto other Transfer Stations.

For more information, contact your service representative.

This function can only be used if the machines are made by the same manufacturer.

# Sending the transfer result report

This machine compares the fax number of the Requesting Party with the Requesting Party's number programmed as a Quick Dial or Speed Dial. If the lower five digits of the two numbers match, it sends the Transfer Result Report to the Requesting Party.

For example:

 Requesting Party's own dial number:

001813-11112222

• Transfer Station's Quick Dial:

03-11112222

#### Transfer result report

This reports whether transmission to the End Receivers was successful or not.

# Preparation

Program the Requesting Party fax number into a Quick Dial key in advance.

Program your own fax number. See p.169 "Transfer Report".

Program the Polling ID. See p.170 "Programming a Polling ID".

When the Transfer Station has transferred the message to all End Receivers, it sends the Transfer Result Report back to the Requesting Party. The machine prints the report if it cannot be sent back to the Requesting Party. You must program the fax number of the Requesting Party as a Quick Dial in the Transfer Station.

#### Note

☐ You can set whether a portion of the original image is printed on the report with the User Parameters. See p.147 "Changing the User Parameters" (switch 04, bit 7).

# **JBIG Reception**

The optional fax function upgrade unit is required.

If you use JBIG (Joint Bi-level Image Experts Group) compression, you can send photographic originals faster than with other methods of compression. You can only use this function with G3 line type. It allows you to receive messages sent in the JBIG format through JBIG Transmission.

# **?** Limitation

☐ If ECM is turned off, JBIG Reception is unavailable.

#### Note

☐ When the optional extra G3 interface unit is installed, JBIG receptions of G3-2 and G3-3 lines are as standard.

# **Auto Fax Reception Power-up**

This machine can be set to shut down automatically if no one has used it for a while. In these situations, even though the operation switch is off, the machine can still receive incoming messages as long as the main power switch is on.

# **#Important**

☐ Reception is not possible if both the operation switch and main power switch are turned off.

- ☐ You can set whether messages are printed as soon as they are received (Immediate Reception) with the User Parameters. See p.147 "Changing the User Parameters" (switch 14, bit 0).
- ☐ You can also have fax messages received by Memory Reception (Substitute Reception) printed after the machine is turned on.

# **Printing Options**

# **Print Completion Beep**


When this function is turned on, the machine beeps to let you know when a received message has been printed.

### Note

☐ You can alter the volume of the beep or turn it off completely (set the volume to the minimum level). See p.47 "Adjusting the Volume", Facsimile Reference < Basic Features>.

### **Checkered Mark**

When this function is turned on, a Checkered Mark is printed on the first page of fax messages to help you separate them.




# Note

☐ You can turn this function on or off using Reception Setting. See p.132 "Reception Setting".

# **Center Mark**

When this function is turned on, marks are printed halfway down the left side and at the top center of each page received. This makes it easy for you to position a hole puncher correctly when you file received messages.



**𝒯** Note

- ☐ The Center Mark may deviate a little from the exact center of the edge.
- ☐ You can turn this function on or off using Reception Setting. See p.132 "Reception Setting".

# **Reception Time**

You can have the date and time printed at the bottom of the message when it is received. You can turn this function on or off using Reception Setting. See p.132 "Reception Setting".


#### Note

- ☐ When a received message is printed on two or more sheets, the date and time is printed on the last page.
- ☐ The date and time when the message was printed can also be recorded on the message. If you need this function, contact your service representative.

# **Two-Sided Printing**


The optional duplex unit is required.

You can have a received message printed on both sides of a sheet. You can turn this function on or off using Reception Setting. See p.132 "Reception Setting".



#### Limitation

☐ To use this function, all pages of the received document must be of the same size—inform the sending party of this beforehand if necessary. You must also have paper set in your machine of the same size as that sent by the sending party. In Two-Sided Printing, this machine will correctly receive in A3 $\square$ , B4 JIS (Japanese Industrial Standard) □, A4 □ □, B5 JIS □□, A5  $\square$   $\square$  (11"×17" $\square$ , 81/2"×14" $\square$ ,  $8^{1}/_{2}$ "×11"  $\square \square$ ,  $8^{1}/_{2}$ "×5 $^{1}/_{2}$ "  $\square$ ). The following table shows the results that can be achieved when receiving with this machine.




- ☐ This function works only when all pages are of the same width and received into memory.
- ☐ This function cannot be used with Combine two originals.

### Note

- ☐ The machine will use Memory Reception for Two-Sided Printing.
- ☐ Printouts may vary depending on how the sender sets the originals.
- ☐ You can select to have messages only from selected senders printed in this way. See p.152 "Special Senders to Treat Differently".
- ☐ Stored documents of the same size are printed on the same paper. Some stored documents may be unavailable for this printing option.


#### 180-Degree Rotation Printing

When printing on both sides of the paper, this machine rotates images as shown in the diagram.



# **Multi-copy Reception**


If you switch this function on, multiple copies of each incoming fax message will be printed. You can also select to have multiple copies made of messages from particular senders. See p.152 "Special Senders to Treat Differently". See p.132 "Reception Setting".



- ☐ The maximum number of copies that can be made for each message is 10.
- ☐ When you are using the Multi-Copy function with specified senders, the maximum number of copies is 10.
- ☐ You can turn this function on or off using Reception Setting. See p.132 "Reception Setting".
- ☐ The machine will use Memory Reception for Multi-copy Reception.

# **Image Rotation**

If you have set paper in the standard tray  $\square$ , incoming fax messages will be rotated automatically to fit onto the paper.




#### Note

☐ You can choose to have received messages printed from a specified tray. See p.132 "Reception Setting".

# **Combine Two Originals**

When two messages of the same size and orientaion are received consecutively, they are printed on a single sheet when you turn this function on. This can help you economize on paper.



• Two A5  $\square$  messages are printed side by side on a sheet of A4  $\square$ .

- Two B5 JIS ☐ messages are printed side by side on a sheet of B4 JIS ☐.
- Two A4 messages are printed side by side on a sheet of A3 .
- Two 8<sup>1</sup>/<sub>2</sub>"×5<sup>1</sup>/<sub>2</sub>" □ messages are printed side by side on a sheet of 8<sup>1</sup>/<sub>2</sub>"×11" □.
- Two 8<sup>1</sup>/<sub>2</sub>"×11" messages are printed side by side on a sheet of 11"×17" □.


#### Limitation

- ☐ This function does not work with messages larger than A5 ☐, B5 JIS ☐, A4 ☐, 8¹/₂" × 11" ☐ or 8¹/₂" × 5¹/₂" ☐. When A5 ☐, B5 JIS ☐, A4 ☐, 8¹/₂" × 11" ☐ or 8¹/₂" × 5¹/₂" ☐ size paper is loaded in the machine, each page of the received message is printed on a single sheet.
- ☐ If paper matching the size and orientation of a received document is unavailable, "Combine two originals" is not possible.
- ☐ When Combine two originals and 2-Sided Printing are selected at the same time, Combine two originals takes priority and 2-Sided Printing is canceled.

- ☐ You can turn this function on or off with the User Parameters. See p.147 "Changing the User Parameters" (switch 10, bit 1).
- ☐ This function uses Memory Reception.

# Page Separation and Length Reduction

When the size of a received message is longer than the paper loaded in the machine, each page of the message can be split and printed on several sheets, or reduced and printed on a single sheet. For example, this function splits the message if the message length is 20 mm (0.79") or longer than the paper used. The message is reduced if it is less than 20 mm (0.79"). When a message is split, an asterix (\*) is inserted at the split position and about 10 mm (0.39") of the split area is duplicated on the top of the second sheet.




ND1X01E1

### **𝚱** Note

- ☐ Your service representative can customize this function with the following settings:
  - Reduction
  - Print split mark
  - Overprinting
  - Overprinting length
  - Guideline for split
- ☐ You can adjust the overprinting and reduction lengths within the following ranges:
  - Overprinting length: 4 mm (0.16"), 10 mm (0.39"), 15 mm (0.59")
  - Guideline for split: 5-155 mm (5 mm steps)/0.2"-6.1" (0.2" steps)

# **Reverse Order Printing**


Normally, received pages are printed and stacked on the tray in the order they are received. If you turn this function on, the machine will start printing the message from the last page received.



- ☐ You can turn this function on or off using Reception Setting. See p.132 "Reception Setting".
- ☐ When this function is on, the first page will be printed last.
- ☐ This function uses Memory Reception.

# Page Reduction

If you receive a message that is longer than the paper in the cassette, the machine usually prints it on two pages. If you turn this function on, the machine reduces the width and length of the received image so that it will fit on one page. If A4D paper is loaded and a message of B4 JISD size is received, the machine will reduce the message to a single A4D sheet.



# Note

- ☐ You can turn this function on or off with the User Parameters. See p.147 "Changing the User Parameters" (switch 10, bit 3).
- ☐ When this function is used, the printing quality may not be as good as usual.

# 

p.88 "Page Separation and Length Reduction"

# TSI Print (Transmitting Subscriber Identification Print)

Usually the sender's Fax Header is printed on received messages. If the sender has not programmed their Fax Header, you will not be able to identify them. However, if you turn this function on, the sender's Own Name or Own Fax Number is printed instead so you can find out where the message came from. See p.41 "Initial Settings and Adjustments", Facsimile Reference < Basic Features>.

#### Note

☐ You can turn this function on or off in the User Parameters. See p.147 "Changing the User Parameters" (switch 02, bit 3).


# When There Is No Paper of the Correct Size

If there is no paper in your machine that matches the size of a received message, the machine will choose a paper size based on the paper available. For example, if your machine has  $8^1/2"\times11"$  and A3 $\square$  loaded and you receive a A4 $\square$  size message, check the A4 $\square$  column of the following table. The paper size at the top has highest priority. In this case, since  $8^1/2"\times11"$  is given a higher priority than A3 $\square$ , the message is printed on  $8^1/2"\times11"$  .

If only B5 JIS□ is loaded and you receive an A3□ message, the received message is stored in memory and not printed.

#### Priority Table

Image Rotation



Page reduction	Disabled
Reduction in Subscan Direction	Enabled
Page Separation Threshold	20 mm (0.79")
Width or Length Priority	Width

• DD and DD indicate that the message is split over two pages of paper with the orientation and size shown.

# **𝚱** Note

□ Paper placed in the bypass tray is not usually selected for printing a received message. However, you can use this tray if you select the bypass tray as the main paper tray using Reception with Specified Senders. See p.152 "Special Senders to Treat Differently".

- ☐ Widths that this machine can receive are A4, B4 JIS, and A3. Any messages narrower than A4 are sent as A4 width with the length unchanged.
- ☐ The paper size used to print a received message may be different from the size of the sent original.
- ☐ If you specify a receiving tray with the setting priority under System Settings, the messages may be received in a different order by setting the priority table. The priority tray may be used only when the document received is the same size as the priority tray.

# 

GEPRIONE

p.88 "Page Separation and Length Reduction"

p.89 "Page Reduction"


p.87 "Image Rotation"

# **Just Size Printing**

If you turn this function on and no paper tray is stocked with paper of a suitable size to print a received document, a message will appear on the display prompting you to load paper of the required size. When you have loaded new paper, you can then print the message.

Two messages can appear:

Paper Cassette



#### Bypass Tray



#### Limitation

- ☐ If the paper tray is pulled out or the machine runs out of the specified size of paper, the message will not be printed. Be sure the paper tray is inserted.
- ☐ The action that follows pressing **[Exit]** varies depending on the status of the machine when the message occurred.
  - If any received documents or reports were being printed automatically, the printer automatically continues printing from where it left off.
  - If any documents or reports were being printed manually, the printer does not resume printing. Perform the operation from the beginning again.

# **𝚱** Note

☐ You can turn this function on or off with the User Parameters. See p.147 "Changing the User Parameters" (switch 05, bit 5).

#### **Setting Priority Trays**

With the same size of paper loaded into multiple trays, you can make the machine use one tray for one function and another tray for another function. For example, you may load white A4 paper into tray 1 to use when making copies, and yellow A4 paper into tray 2 to use when printing received faxes. You can then easily identify for which purpose paper has been output. You can perform this setting using System Settings. See the *General Settings Guide*.

#### Note

□ When a different size of document from the priority tray is received, the tray containing the same size of paper as the received document is used.

# Having Incoming Messages Printed on Paper from the Bypass Tray

You can have messages sent from Specified Senders printed on paper from the bypass tray. This is useful if you need messages printed on a size of paper not stocked in the paper cassette(s).

You can load a maximum of 100 sheets of standard paper in the bypass tray.

# **𝒯** Note

☐ Before you can use this function, you need to turn on Authorized Reception (Initial Setup Reception Mode settings), program the Specified Senders (Key Operator Settings) along with the paper. See p.132 "Reception Setting". See p.152 "Special Senders to Treat Differently".

- ☐ The print area is determined by the optional expansion memory, resolution, and the vertical length of the originals.
- ☐ If paper longer than 600 mm is used, the paper may get wrinkled, it may not be sent, or a paper jam may occur.
- ☐ The machine can detect A4☐, A3☐(8¹/₂"×11"☐, 11"×13"☐) paper sizes. When you load any other size, specify the paper size. See p.158 "Programming Bypass Tray Paper Size".
- ☐ When using tray 1 of the optional 1000-sheet finisher, paper is output to the tray even with non-standard sizes selected.
- ☐ If the specified paper size and the size of paper set in the bypass tray do not match, paper jams may occur, or the image may be truncated.
- ☐ If messages are printed on paper smaller than A4, the image may be truncated, or split across sheets.
- ☐ If you use this function, Image Rotation and 180-Degree Rotating Printing are not possible.

# Where Incoming Message are Delivered - Output Tray

# **Specifying Tray for Lines**

The optional extra G3 interface unit is required.

You can specify the document feeding tray for each port. For example, you can specify documents received through the G3 -1 port to be fed to the "Internal Tray 1" and documents received through the G3 -2 port to be fed to the "Internal Tray 2", facilitating separation of files.

# **𝒜** Note

☐ To use this function, specify the port and destination using [Specify Tray for Lines]. See p.132 "Reception Setting".

# **Tray Shift**

The optional finisher or shift sort tray unit is required.

When the optional finisher unit is selected for fax output, you can use the Tray Shift function whenever a fax or report is printed.

This is useful for separating faxes stacked in the finisher output tray. For example, if the previous incoming fax was output to the left, the next incoming fax will be output to the right and vice-versa.

# 

☐ You can turn this function on or off with the User Parameters. See p.147 "Changing the User Parameters" (switch 19, bit 0).